

## Power Range:

3-phase 230V series:5.5kW~37kW (7.5~50HP) 3-phase 460V series:5.5kW~75kW (7.5~100HP)



#### **IABU Headquarters**

Delta Electronics, Inc.
Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

#### Asia

Delta Electronics (Jiangsu) Ltd.

Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province,
People's Republic of China (Post code: 215200)
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

#### Delta Greentech (China) Co., Ltd.

238 Min-Xia Road, Pudong District, ShangHai, P.R.C. Post code: 201209 TEL: 86-21-58635678 / FAX: 86-21-58630003

#### Delta Electronics (Japan), Inc.

Tokyo Office 2-1-14 Minato-ku Shibadaimon, Tokyo 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

#### Delta Electronics (Korea), Inc.

1511, Byucksan Digital Valley 6-cha, Gasan-dong, Geumcheon-gu, Seoul, Korea, 153-704 TEL: 82-2-515-5303 / FAX: 82-2-515-5302



4 Kaki Bukit Ave 1, #05-05, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

#### Delta Electronics (India) Pvt. Ltd.

Plot No 43 Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: 91-124-4874900 / FAX: 91-124-4874945

#### **Americas**

**Delta Products Corporation (USA)** 

Raleigh Office P.O. Box 12173,5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3800 / FAX: 1-919-767-8080

#### Delta Greentech (Brasil) S.A

Sao Paulo Office Rua Itapeva, 26 - 3° andar Edificio Itapeva One-Bela Vista 01332-000-São Paulo-SP-Brazil TEL: +55 11 3568-3855 / FAX: +55 11 3568-3865

#### Europe

Deltronics (The Netherlands) B.V.

Eindhoven Öffice

De Witbogt 15, 5652 AG Eindhoven, The Netherlands

TEL: 31-40-2592850 / FAX: 31-40-2592851



\*We reserve the right to change the information in this catalogue without prior notice.



**VFD-VJ** 

User Manual

Delta's high-performance Hybrid servo drive

Thank you for choosing Delta's high-performance Hybrid servo drive VFD-VJ Series dedicated to plastic injection molding machine. The VFD-VJ series products are made of high quality components and materials that incorporate the latest microcontroller technology.

This manual is to be used for the installation, parameter setting, troubleshooting, and daily maintenance of the Hybrid servo drive. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the Hybrid servo drive. Keep this operating manual at hand and distribute to all users for reference.

To ensure the safety of operators and equipment, only qualified personnel familiar with Hybrid servo drive are to do installation, start-up and maintenance. Always read this manual thoroughly before using VFD-VJ series Hybrid Servo Drive, especially the WARNING, DANGER and CAUTION notes. Failure to comply may result in personal injury and equipment damage. If you have any questions, please contact your dealer.

Firmware version: V2.03

#### PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- ☑ AC input power must be disconnected before any wiring to the Hybrid servo drive is made.
- ☑ Even if the power has been turned off, a charge may still remain in the DC-link capacitors with hazardous voltages before the POWER LED is OFF. Please do not touch the internal circuit and components. For safe maintenance, use a multimeter to measure the voltage across the +1 and terminals. The measured value should be lower than 25Vdc for the system to operate normally.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Please do not touch these components or the circuit boards before taking anti-static measures. Never reassemble internal components or wiring.
- Ground the Hybrid servo drive using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ This series of products is used to control the three-phase induction motors and permanent magnet synchronous motors. It cannot be used for single-phase motors or for other purposes.
- ☑ This series of products cannot be used on occasions that may endanger personal safety.
- ☑ Please prevent children or unauthorized personnel from approaching the Hybrid servo drive.



- ☑ Never connect the Hybrid servo drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.
- ☑ DO NOT use Hi-pot test for internal components. The semi-conductor used in Hybrid servo drive easily damage by high-voltage.
- ☑ Even if the 3-phase AC motor is stop, a charge may still remain in the main circuit terminals of the AC motor drive with hazardous voltages.
- ☑ Only qualified persons are allowed to install, wire and maintain AC motor drives.
- ☑ When the Hybrid servo drive uses an external terminal as its source of operation commands, the motor may start running immediately after the power is supplied. In this case, it may be dangerous to any on-site personnel.



- ☑ DO NOT install the Hybrid servo drive in a place subjected to high temperature, direct sunlight, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
- ☑ Only use Hybrid servo drives within specification. Failure to comply may result in fire, explosion or electric shock.
- When the motor cable between Hybrid servo drive and motor is too long, the layer insulation of the motor may be damaged. Please add an AC output reactor to prevent damage to the motor. Refer to appendix A Reactor for details.
- ☑ The rated voltage for Hybrid servo drive must be  $\leq$  240V ( $\leq$  480V for 460V models) and the mains supply current capacity must be  $\leq$  5000A RMS ( $\leq$ 10000A RMS for the  $\geq$  40hp (30kW) models).

## NOTE

■ The content of this manual may be revised without prior notice. Please consult our distributors or download the most updated version at http://www.delta.com.tw/industrialautomation

# **Table of Contents**

1.	Use and Installation	
	1-1 Receiving and Inspection	1-2
	1-2 Product Specifications	1-3
	1-3 Selection of Hybrid Servo Drives and Motors	1-4
	1-4 Product Installation	1-6
	1-5 Product Dimensions	1-11
2.	Wiring	
	2-1 Description of Wiring	2-2
	2-2 Description of Terminals on Main Circuit	2-7
	2-3 Description of Terminals on Control Circuit	2-11
3.	Machine Adjustment Procedure	
	3-1 Description of Control Panel	3-2
	3-2 Machine Adjustment Procedure	3-4
4.	Description of Parameters	
	4-1 Summary of Parameters	4-2
	4-2 Detailed Description of Parameters	4-9
5.	Fault Diagnostic Methods	
	5-1 Error Messages	5-2
	5-2 Over Current OC	5-7
	5-3 Ground Fault Factor GFF	
	5-4 Over Voltage OV	5-8
	5-5 Low Voltage Lv	5-8
	5-6 Over Heat OH1	
	5-7 Overload OL	
	5-8 Phase Loss PHL	
	5-9 Electromagnetic/Induction Noise	
	5-10 Environmental Condition	5-12
6.	Suggestions and Error Corrections for Hybrid Servo Drives	
	6-1 Maintenance and Inspections	6-2

	6-2 Greasy Dirt Problem	6-2
	6-3 Fiber Dust Problem	6-5
	6-4 Erosion Problem	
	6-5 Industrial Dust Problem	6-7
	6-6 Wiring and Installation Problem	6-8
	6-7 Multi-function Input/Output Terminals Problem	6-9
7.	Recommended Operations for Customers and Troubleshooting	
	7-1 Regular Maintenance and Check	7-2
	7-2 Oil Contamination	7-6
	7-3 Lint Issue	7-7
	7-4 Corrosion Issue	7-9
	7-5 Dust Issue	7-10
	7-6 Installation and Wiring/Connection Issue	7-11
	7-7 Multi-function Input/Output Terminal Application Issue	7-12
Ap	pendix A Optional Accessories	
	A-1 Braking Resistor Selection Chart	A-2
	A-2 Non-fuse Circuit Breaker	A-6
	A-3 Fuse Specification	A-6
	A-4 Reactor	A-7
	A-4-1 AC Input Reactor Recommended Value	A-7
	A-4-2 AC Output Reactor Recommended Value	A-7
	A-4-3 Zero Phase Reactor	A-9
	A-4-4 DC Reactor	A-10
	A-5 Digital Keypad KPV-CE01	A-11
	A-6 Speed Feedback PG Card Selection	A-15
	A-7 Communication Card	
	A-8 EMI Filter	A-20

# 1. Description of Hybrid Servo Drives

- 1-1 Receiving and Inspection
- 1-2 Product Specifications
- 1-3 Overview of Hybrid Servo Systems
- 1-4 Product Installation
- 1-5 Product Dimensions

The Hybrid servo drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the Hybrid servo drive should be stored properly when it is not to be used for an extended period of time. Storage conditions are:



- ☑ Store in a clean and dry location free from direct sunlight or corrosive fumes.
- ☑ Store within an ambient temperature range of -20 °C to +60 °C.
- ☑ Store within a relative humidity range of 0% to 90% and non-condensing environment.
- ☑ Avoid storing the product in an environment containing corrosive gases and liquids.
- ☑ DO NOT place on the ground directly. It should be stored properly. Moreover, if the surrounding environment is humid, you should put exsiccator in the package.
- ☑ DO NOT store in an area with rapid changes in temperature. It may cause condensation and frost.
- ☑ If the Hybrid servo drive is stored for more than 3 months, the temperature should not be higher than 30 °C. Storage longer than one year is not recommended, it could result in the degradation of the electrolytic capacitors.
- ☑ When the Hybrid servo drive is not used for longer time after installation on building sites or places with humidity and dust, it's best to move the Hybrid servo drive to an environment as stated above.

# 1-1 Receiving and Inspection


This VFD-VJ Hybrid servo drive has gone through rigorous quality control tests at the factory before shipment. After receiving the Hybrid servo drive, please check for the following:

- ✓ Inspect the unit to assure it was not damaged during shipment.
- ☑ Make sure that the part number indicated on the nameplate corresponds with the part number of your order.


If the registered information does not match your purchase order, or if the product has any problem, please contact the dealer or distributor.

## Nameplate Information


Let us take the 15HP/11kW 230V 3-Phase model as an example.



## **Model Explanation**



## Series Number Explanation



# 1-2 Product Specifications

## Specifications of 230V Series

Frame	No.	C D E2					2				
Model	No. VFDVLA-J	055	075	110	150	185	220	300	370		
Power	(KW)	5.5	5.5     7.5     11     15     18.5     22     30     37       7.5     10     15     20     25     30     40     50       33     46     62     90     119     119     180     248       37     54     70     106     140     140     204     292		37						
Horse I	Power (HP)	7.5	10	15	20	25	30	40	50		
Output	Output Current for Continuous Operation Over 60 sec (A)	33	46	62	90	119	119	180	248		
	Output Current for Continuous Operation Over 20 sec (A)	37	54	70	106	140	140	204	292		
	Input Current (A)	25	31	47	60	80	90	106	126		
Power	Tolerable Input Voltage Variation	Three-phase 200~240V 50/60Hz									
Supply	Tolerable Supply Voltage Variation				±10% (18	30~264V)					
	Tolerable Supply Frequency Variation	±5% (47~63Hz)									
	Weight (kg)	8	10	10	13	13	13	36	36		

## Specifications of 460V Series


-													
Frame	No.		С			D			E1		E2		
Model	No. VFDVLA-J	055	075	110	150	185	220	300	370	450	550 750		
Power	(KW)	5.5	7.5	11	15	18.5	22	30	37	45	55 75		
Horse	Power (HP)	7.5	10	15	20	25	30	40	50	60	75 100		
Output	Output Current for Continuous Operation Over 60 sec (A)	21	27	36	46	58	62	102	124	155	187	255	
	Output Current for Continuous Operation Over 20 sec (A)	25	32	42	54	68	78	120	146	182	220	300	
	Input Current (A)	14	18	24	31	39	47	56	67	87	101	122	
Power	Tolerable Input Voltage Variation	Three-phase 380~480V, 50/60Hz											
Supply	Tolerable Supply Voltage Variation					±10%	% (342~5	28V)					
	Tolerable Supply Frequency Variation	±5% (47~63Hz)											
	Weight (kg)	8	10	10	13	13	13	36	36	36	50	50	

#### **Common Features**

Со	ntrol method	SVPWM					
Spe	eed Detector	Resolver / Incremental Encoder					
Speed	Command Input	DC 0~10V, 3-point calibration of analog input is supported					
Pressur	e Command Input	DC 0~10V, 3-point calibration of analog input is supported					
Pressur	e Feedback Input	DC 0~10V					
General P	urpose Input Signal	5 ch DC24V 8mA					
General Pu	urpose Output Signal	2 ch DC24V 50mA, 1 ch Relay output					
Analog	g Output Voltage	1 ch dc 0~10V					
Optional Peripheral	Speed Feedback PG Card	Mandatory (Refer to Appendix A-5)					

Accessories	Braking Resistor	Mandatory (Refer to Appendix A-1)						
		Mandatory (It must has an output signal ranging within 0~10V, which can be configured						
	Pressure Sensor	by Parameters 03-10~03-11;						
		The maximum pressure can be configured by Parameter 00-08)						
	EMI Filter	Optional (Refer to Appendix A-7)						
	Motor Protection	Electronic thermal relay protection						
	Over Current Protection	Over current protection is activated at 300% of the rated current						
Protection	Ground Leakage Current Protection	Activated when the leakage current is higher than 50% of the drive's rated current						
Feature	Voltage Protection	Over Voltage Level: Vdc>400/800 V; Low Voltage Level: Vdc<200/400 V						
	Input Power Supply Over Voltage Protection	Metal Oxide Varistor (MOV)						
	Over Temperature Protection	Built-in temperature sensor						
	Protection Level	NEMA 1/IP20						
	Operation Temperature	-10°C~45°C						
	Storage Temperature	-20°C~60°C						
Environment	Humidity	Below 90% RH (non-condensing)						
	Vibration	1.0G below 20Hz, 0,6G at 20~60 Hz						
	Cooling System	Forced air cooling						
	Installation Altitude	Altitude below 1,000m, keep from corrosive gasses, liquid and dust						
Internat	ional Certification	(€						

# 1-3 Overview of Hybrid Servo Systems



# 1-3-1 Selection of Hybrid Servo Drives and Motors

Due to the differences in the hydraulic system in practical applications, the following choice of drives and motors is provided as a reference.

In the following example, a flow of 64L/min and maximum holding pressure of 175Bar are used.

#### Pump Displacement per Revolution

Based on the maximum flow of the system (L/min), the pump displacement per revolution (cc/rev) can be calculated.

Example: If the maximum flow of the system is 64L/min and the highest rotation speed of the motor is 2000rpm, the displacement per revolution is 64/2000\*1000 = 32 cc/rev.

#### 2. Maximum Torque of the Motor

Based on the maximum pressure (Mpa) and pump displacement per revolution (cc/rev), the maximum torque can be calculated.

Example: For the required maximum pressure of 17.5 Mpa and pump displacement per revolution of 32cc/rev

Torque = 17.5\*32\*1.3/(2\*pi) = 116 N-m, where the factor 1.3 is used to compensate the total loss in the system.

#### 3. Rated Torque and Rated Power of the Motor

At the maximum pressure for the holding pressure, the required torque should be 1.5 times of the motor's rated torque or less (depending on the data provided by the motor's

manufacturer). Over such an operating condition, the over-temperature of the motor may easily occur. Let us take the factor 1.5 as an example, if the rated torque of the motor is 77 N-m, the motor with a power of 12kW\* and a rated speed of 1500 rpm can be chosen. \*The power of the motor is calculated by using  $P(W) = T(N-m) \times \omega(rpm \times 2\pi/60)$ 

#### 4. Maximum Current of the Motor

Example: Check the parameter kt (Torque/A) in the motor's specifications, if kt = 3.37, the maximum current is approximately 116/3.37 = 34A at the maximum torque of 116 N-m.

#### 5. Selection of Matched Hybrid Servo Drive

Example: Look up the over-load capability for each Hybrid servo drive in the product specification chart

If the holding pressure is at the maximum pressure of 17.5 Mpa, and a pump of 32cc/rev is used, the required motor current is approximately 34A For such a current value, the following models can be chosen VFD075VL43A-J, the overload may occur within 20 sec. VFD110VL43A-J, the overload may occur approximately after 60 sec.



If there is no suitable motor that meets the specifications, a motor with a higher rated value can be used instead.

For any information about the Hybrid servo drives or any assistance in detailed configuration of your company's products, please contact the manufacturer.

## 1-3-2 Selection of Pump for Hybrid Servo Motor

Select a pump with a suitable displacement based on the required flow rate and motor speed;

- If low noise is required, you can choose the screw pump or internal gear type. If a high volumetric efficiency is required, you can choose the piston pump or dual displacement piston pump.
- Comparison of Commonly Used Pump (This may vary for different pump manufacturers).


Type of Oil Pump	Volumetric Efficiency	Flow Pulsation	Rotation Speed	Noise
Internal Gear Pump	ernal Gear Pump Low		Medium	Low
Piston Pump	High	Low	Low	High
Screw Pump	Medium	High	High	Medium


# 1-4 Product Installation

Please install the Hybrid servo drive under the following environmental conditions to ensure safety of use:

Ambient temperature	-10°C~ +45°C				
Relative Humidity	<90% (non-condensing)				
Pressure	86 ~ 106 kPa				
Installation Altitude	<1000m				
Vibration	<20Hz: 9.80 m/s <sup>2</sup> (1G) max; 20~50H:5.88 m/s <sup>2</sup> (0.6G)				
	max				
Ambient temperature	-20°C~ +60°C (-4°F ~ 140°F)				
Relative Humidity	<90% (non-condensing)				
Pressure	86 ~ 106 kPa				
Vibration	$<20$ Hz: 9.80 m/s <sup>2</sup> (1G) max; 20 $\sim$ 50Hz: 5.88 m/s <sup>2</sup>				
	(0.6G) max				
Loval O. Applicable to	footom, any incompant with law to modium contamination				
Level 2. Applicable to	factory environment with low-to-medium contamination				
	Relative Humidity Pressure Installation Altitude Vibration  Ambient temperature Relative Humidity Pressure Vibration				

# Space for Installation





НР	W	Н
nP	mm (inch)	mm (inch)
7.5-20HP	75 (3)	175 (7)
25-75HP	75 (3)	200 (8)
100HP	75 (3)	250 (10)


- 1. Mount the Hybrid servo drive vertically on a flat vertical surface object by screws. Other directions are not allowed.
- 2. The Hybrid servo drive will generate heat during operation. Allow sufficient space around the unit for heat dissipation.

- 3. The heat sink temperature may rise to 90°C when running. The material on which the Hybrid servo drive is mounted must be noncombustible and be able to withstand this high temperature.
- 4. When Hybrid servo drive is installed in a confined space (e.g. cabinet), the surrounding temperature must be within -10 ~ 40°C with good ventilation. DO NOT install the Hybrid servo drive in a space with bad ventilation.
- 5. When installing multiple Hybrid servo drives in the same cabinet, they should be adjacent in a row with enough space in-between. When installing one Hybrid servo drive below another one, use a metal separation between the Hybrid servo drives to prevent mutual heating.
  - ☑ Prevent fiber particles, scraps of paper, saw dust, metal particles, etc. from adhering to the heat sink.

# Lifting

Please carry only fully assembled Hybrid servo drives as shown in the following. Lift the Hybrid servo drive by hooking the lifting hole.


40-100HP (Frame No. E)



# Flange Mounting

#### Step 1:

Please take out the 16 screws (8 screws for each top and bottom side of the drive) and remove the fixed plate 1 and fixed plate 2) as shown in the following figures.



#### Step 2:

place the 8 screws back in to secure the fixed plate 1 and fixed plate 2 (as shown in the following figures) with the following torque.

Frame No. C: 14-17kgf-cm


[12.2-14.8in-lbf]


Frame No. D: 20-25kgf-cm

[17.4-21.7in-lbf]

Frame No. E: 20-25kgf-cm


[17.4-21.7in-lbf]






Step 3:


Please notice that it doesn't need to put those 8 screws shown in the following figures back to the drive. Moreover, please make sure that these 2 different fixed plates are put in the correct side as shown in the figures.





# **1-5 Product Dimensions**

Frame No. C










Unit: mm [inch]

Frame No.	W	W1	Н	H1	H2	Н3	D	Ø	Ø1	Ø2	Ø3
С	235	204	350	337	320		136	6.5		34	22
	[9.25]	[8.03]	[13.78]	[13.27]	[12.60]	-	[5.35]	[0.26]	-	[1.34]	[0.87]



Frame No. C: VFD055VL23A/43A-J, VFD075VL23A/43A-J, VFD110VL23A/43A-J,

Frame No. D




Unit: mm [inch]

Frame No.	W	W1	Н	H1	H2	Н3	D	Ø	Ø1	Ø2	Ø3
,	255.0	226.0	403.8	384.0	360.0	21.9	168.0	8.5	44	34	22
ט	[10.04]	[8.90]	[15.90]	[15.12]	[14.17]	[0.86]	[6.61]	[0.33]	[1.73]	[1.34]	[0.87]



 $\textbf{Frame No. D:} \ VFD150VL23A/43A-J, \ VFD185VL23A/43A-J, \ VFD220VL23A/43A-J, \ VFD220VL23$ 

Frame No. E



Unit: mm [inch]

Frame No.	W	W1	Н	H1	H2	D	D1:	D2:	S1	S2	S3
E1	370.0	335.0		589.0	560.0	260.0	132.5	18.0	13.0	13.0	18.0
_ <u>_</u>	[14.57]	[13.19]	-	[23.19]	[22.05]	[10.24]	[5.22]	[0.71]	[0.51]	[0.51]	[0.71]
E2	370.0	335.0	595.0	589.0	560.0	260.0	132.5	18.0	13.0	13.0	18.0
	[14.57]	[13.19]	[23.43]	[23.19]	[22.05]	[10.24]	[5.22]	[0.71]	[0.51]	[0.51]	[0.71]



Frame No. E1: VFD300VL43A-J, VFD370VL43A-J, VFD450VL43A-J,

 $\textbf{Frame No. E2:} \ VFD300VL23A-J, \ VFD370VL23A-J, \ VFD550VL43A-J, \ VFD750VL43A-J, \ VF$ 

# 2. Wiring

- 2-1 Description of Wiring
- 2-2 Description of Terminals on Main Circuit
- 2-3 Description of Terminals on Control Circuit

After removing the front cover, check if the power and control terminals are clear. Be sure to observe the following precautions when wiring.

- ☑ Make sure that power is only applied to the R/L1, S/L2, T/L3 terminals. Failure to comply may result in damage to the equipments. The voltage and current should lie within the range as indicated on the nameplate
- ☑ All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock.
- ☑ Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration




- ☑ It is crucial to turn off the Hybrid servo drive power before any wiring installation are made. A charge may still remain in the DC bus capacitors with hazardous voltages even if the power has been turned off therefore it is suggested for users to measure the remaining voltage before wiring. For your personnel safety, please do not perform any wiring before the voltage drops to a safe level < 25 Vdc. Wiring installation with remaining voltage condition may cause sparks and short circuit.</p>
- ☑ Only qualified personnel familiar with Hybrid servo drives is allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.




- ☑ Make sure that power is only applied to the R/L1, S/L2, T/L3 terminals. Failure to comply may result in damage to the equipment. The voltage and current should lie within the range as indicated on the nameplate.
- ☑ Check following items after finishing the wiring:
  - 1. Are all connections correct?
  - 2. No loose wires?
  - 3. No short-circuits between terminals or to ground?

# 2-1 Description of Wiring


Users must connect wires according to the circuit diagrams on the following pages. Standard wiring diagram of the VFD-VJ Hybrid servo drive in factory



#### Note 1\*




Applicable to the models of 30kW or above (including 30kW models with optional internal brake unit)




#### Note 2\*

#### EMVJ-PG01R/PG02R



#### EMVJ-PG01U




#### Note 3\*

If the motor's temperature protection switches are normally close type, please set the Parameter 03-04 to 4 first, and then carry out the wiring. In this case, the drive may display the EF1 error message. Just clear the message.

#### Note 4\*

Please select the R value in accordance with the thermistor specifications. The related trigger level can be configured by the Parameters 02-08 to 02-10. If the thermistor of Model Number KTY84 is used, select the R value as  $2k\Omega$  (1/4W)  $\pm$  0.1%, and set the Parameter 02-11 with the value of 1.


#### Multi-pump Operation Mode



- \*1 For firmware version 2.03 and above, the operating commands are given through the communications.

  Therefore, the parameters for the slave is 01-01 = 2
- \*2 For firmware version 2.03 and above, it is not necessary to install this check valve. By selecting the slave parameter 03-21 at the slave to see if the slave will perform the reverse depressurization. Parameters 03-21 = 0 for not performing the reverse depressurization.
- \*3 For firmware version 2.03 and above, the diversion/confluence signal is supplied to only Master 2/Slave. It is not necessary to supply the signal to Master 1.For the following control arrangement, it is necessary to disconnect the communications during diversion.


When the signals are confluence, the communication will be a short circuit When the signals are diversion, the communication becomes an open circuit







- ☑ The wiring of main circuit and control circuit should be separated to prevent erroneous actions.
- ☑ Please use shield wire for the control wiring and not to expose the peeled-off net in front of the terminal.
- ☑ Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube.
- $\ \ \, \square$  Make sure that the leads are connected correctly and the AC drive is properly grounded. (Ground resistance should not exceed 0.1  $\Omega$ .)
- ☑ Use ground leads that comply with local regulations and keep them as short as possible.
- ☑ Multiple VFD-VJ units can be installed in one location. All the units should be grounded directly to a common ground terminal, as shown in the figure below.

  Ensure there are no ground loops.





# 2-2 Description of Terminals on Main Circuit



#### Motor

Terminal Identification	Description
R/L1, S/L2, T/L3	AC line input terminals 3-phase
U/T1, V/T2, W/T3	Output terminals of the Hybrid servo drive that are connected to the motor
+1, +2/B1	Connections for DC reactor to improve the power factor. It needs to remove
	the jumper for installation. (DC reactor is built in for models $\geq$ 22KW)
+2/B1, B2	Connections for Brake Resistor (optional)
	Earth connection, please comply with local regulations



#### Power supply input terminals for the main circuit:

- ☑ Do not connect 3-phase model to one-phase power. R/L1, S/L2 and T/L3 has no phase-sequence requirement, it can be used upon random selection..
- ☑ It is recommend to add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of the AC motor drive. Both ends of the MC should have an R-C surge absorber.
- ☑ Fasten the screws in the main circuit terminal to prevent sparks condition made by the loose screws due to vibration.
- Please use voltage and current within the specification.. Please refer to Chapter1 for the specifications.
- ☑ When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above and not less than 0.1-second operation time to avoid nuisance tripping.
- ✓ Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube.

#### Output terminals for the main circuit:

- When it needs to install the filter at the output side of terminals U/T1, V/T2, W/T3 on the Hybrid servo drive. Please use inductance filter. Do not use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta..
- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of Hybrid servo drives.


#### The terminals of the DC reactor [+1, +2], terminals at DC side [+1, +2/B1]

☑ This is the terminals used to connect the DC reactor to improve the power factor. For the factory setting, it connects the short-circuit object. Please remove this short-circuit object before connecting to the DC reactor.

- ☑ For those models without built-in brake resistor, please connect external brake unit and brake resistor (both of them are optional) to increase brake torque.
- ☑ DO NOT connect [+1, -], [+2, -], [+1/DC+, -/DC-] or brake resistor directly to prevent drive damage.

# **Specifications of the Terminals on the Main Circuit**

#### Frame No. C




Terminals on the main circuit:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3,  $\ \oplus \$ , +1, +2/B1, -, B2


Model	Wire Diameter	Torque	Wire Type
VFD055VL23A-J	10-6 AWG.		
VFD110VL43A-J	(5.3-13.3mm <sup>2</sup> )		
VFD055VL43A-J	12-6 AWG.		
VFD075VL43A-J	(3.3-13.3mm <sup>2</sup> )	30kgf-cm	Stranded copper
\/FD440\/L02A_L	6 AWG.	(26in-lbf)	only <sup>,</sup> 75°C
VFD110VL23A-J	(13.3mm <sup>2</sup> )		
VFD075VL23A-J	8-6 AWG.		
VFDU/5VLZ3A-J	(8.4-13.3mm <sup>2</sup> )		

Wire Type: Stranded copper only, 75°C

The right figure below shows the specifications of the UL certified insulation heat shrink tubing which can withstand 600V, YDPU2.



Frame No. D




Terminals on the main circuit:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, 🗐, +1, +2, -


Model	Wire Diameter	Torque	Wire Type
VFD150VL43A-J VFD185VL43A-J	8-2 AWG. (8.4-33.6mm <sup>2</sup> )		
VFD150VL23A-J	4-2 AWG. (21.1-33.6mm <sup>2</sup> )		
VFD185VL23A-J	3-2 AWG. (26.7-33.6mm <sup>2</sup> )	50Kgf-cm (43.4 lbf-in)	Stranded copper only, 75°C
VFD220VL43A-J	6-2AWG (13.3-33.6mm <sup>2</sup> )	(	orny 70 0
VFD220VL23A-J	3-2AWG (26.7-33.6mm <sup>2</sup> )		

Wire Type: Stranded copper only, 75°C

The right figure below shows the specifications of the UL certified insulation heat shrink tubing which can withstand 600V, YDPU2.



## Frame No. E



#### Terminals on the main circuit:


R/L1, S/L2, T/L3, U/T1, V/T2, W/T3,  $^{\textcircled{1}}$ , +1, +2, -


Model	Wire Diameter	Torque	Wire Type
VFD300VL43A-J		57kgf-cm	
VFD370VL43A-J		(49in-lbf)	Stranded
VFD450VL43A-J	4-2 AWG.	(10111101)	copper
VFD300VL23A-J	(21.2-33.6mm <sup>2</sup> )		only ,
VFD370VL23A-J	(21.2-33.011111)	200kgf-cm	75°C
VFD550VL43A-J		(173in-lbf)	700
VFD750VL43A-J			

Wire Type: Stranded copper only, 75°C

# 2-3 Description of Terminals on Control Circuit

Description of SINK (NPN)/SOURCE (PNP) Mode Selection Terminals





Frame No.	Torque		Wire Diameter
C, D, E	8 kgf-com (6.9 in-lbf)		22-14 AWG (0.3-2.1mm <sup>2</sup> )
	Terminal: 0V/24V	1.6 kgf-com(1.4 in-lbf)	30-16 AWG (0.051-1.3mm <sup>2</sup> )

Terminal	Features	Factory Setting (NPN Mode)	
SON	Run-Stop	Terminal SON-COM: ON for Running; OFF for Stop	
EMG	External error input	External error input	
RES	Reset from error	Reset from error	
MI3	Multi-function input selection 3	Configured as no function in factory	
MI4	Multi-function input selection 4	When it is ON, the input voltage is 24Vdc (Max:30Vdc)	
MI5	Multi-function input selection 5	and then input impedance is $3.75k\Omega$ ; when it is OFF, the	
	•	tolerable leakage current is 10µA.  Common ground for multi-function input terminals	
COM	control signals	common ground for main ranotion input torminals	
+E24V	Common source for digital control signals	+24V 80mA	
DCM	Common ground (Sink) for digital control signals	Common ground for multi-function input terminals	
RA	Error terminal 1 (Relay N.O. a)	Resistive load	
DD	Francisco ( / Dolov N. C. b.)	5A(N.O.)/3A(N.C.) 240VAC 5A(N.O.)/3A(N.C.) 24VDC	
RB	Error terminal 1 (Relay N.C. b)	Inductive load	
RC	Command contact for multi-function output terminals	1.5A(N.O.)/0.5A(N.C.) 240VAC	
IXC	(Relay)	1.5A(N.O.)/0.5A(N.C.) 24VDC	
		The Hybrid servo drive sends various monitoring	
MO1	Multi-function output terminal 1	signals by means of open-collector configuration.	
IVIO	(photocoupler)	Max: 48Vdc/50mA	
		MO1 S	
		MO2	
MO2	Multi-function output terminal 2		
IVIOZ	(photocoupler)		
		internal circuit MCM	
	Common ground for	Max 48Vdc 50mA	
MCM	Multi-function output terminal		
	(photocoupler)		
		Pressure feedback	
РО		Impedance: 200kΩ Resolution: 12 bits	
	PO/PI/QI PO/PI/QI circuit	Range: 0 – 10V = 0 – the maximum pressure feedback	
	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	value (Parameter 00-08)	
		Pressure Command	
PI		Impedance: 200kΩ Resolution: 12 bits	
		Range: $0 - 10V = 0$ – the maximum pressure command	
	ACM Internal circuit	value (Parameter 00-07)	
		Flow rate command	
QI		Impedance: 200kΩ Resolution: 12 bits	
A 1 11		Range: 0 – 10V = 0 – the maximum flow rate	
AUI	Analog Voltage	Impedance: 11.3kΩ	


	+10V AUI circuit  AUI  -10V  internal circuit	Resolution: 12 bits Range: -10 ~ +10VDC
+10V	Power supply for configuration	Power supply for analog configuration +10Vdc 20mA (variable resistance 3~5kΩ)
+24V	Power supply terminal for the pressure sensor	Power supply for the pressure sensor +24Vdc 100mA
AFM	AFM ACM	Impedance: $16.9k\Omega$ (voltage output)  Output current: $20mA$ max  Resolution: $0-10V$ for the maximum operating frequency  Range: $0-10V$ Function Setting: Parameter $00-05$
ACM	Common ground for analog control signals	Common ground terminal for analog control signals

\* Specifications of analog control signal wire: 18 AWG (0.75 mm<sup>2</sup>), with shielded twisted pair

## **Analog Input Terminals (PO, PI, QI, AUI, ACM)**

- ☑ The maximum input voltage of PI, PO, and QI cannot exceed +12V and no more than +/-12V for AUI. Otherwise, the analog input function may become ineffective.
- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- ☑ If the analog input signals(pressure sensor) are affected by noise from the Hybrid servo drive, please connect a capacitor and ferrite core as indicated in the following diagrams:

wind each wires 3 times or more around the core



## **Transistor Output Terminals (MO1, MO2, MCM)**

- ☑ Make sure to connect the digital outputs to the right polarity.
- ☑ When connecting a relay to the digital outputs connect a surge absorber across the coil and check the polarity.

# 3. Control Panel and Machine Adjustment Procedure

- 3-1 Description of Control Panel
- 3-2 Machine Adjustment Procedure




- ☑ Please re-check if the wiring is correct before start running the machine. Particularly, make sure that the output terminals of the Hybrid servo drive, U/T1, V/T2, and W/T3, must not be used as power input terminals. Make sure that the good ground terminal ⊕ is grounded.
- ☑ Make sure that there is no short-circuit or ground short circuit conditions between the terminals or exposed live parts.
- ☑ The power switch can be turned on only with the cover installed.



☑ If any fault occurs during the operation of the Hybrid servo drive and the motor, stop the machine immediately, and refer to "Troubleshooting" to check the cause of the faulty condition. After the Hybrid servo drive stop its output but the main circuit power terminals L1/R, L2/S, and L3/T are not disconnected, if the operator touches the output terminals U/T1, V/T2, and W/T3 of the Hybrid servo drive, electric shock may occur.

# 3-1 Description of Control Panel

# **Appearance of Keypad Control Panel KPVJ-LE01**




- Status Display
   Display the driver's current status.
- 2 LED Display Indicates frequency, voltage, current, user defined units and etc.
- 3 UP and DOWN Key Set the parameter number and changes the numerical data, such as Master Frequenc
- 4 MODE Change between different display mode.
- **5** ENTER Used to enter/modify programming parameters.

## **Description of Displayed Function Items**

Displayed Item	Description
RUN• FWD• REV•	The current frequency set for the Hybrid servo drive
RUN• FWD• REV•	The frequency Hybrid servo drive actually delivers to the motor
RUN• FWD• REV•	The user-defined physical quantity (Parameter 00-04)
RUN• FWD• REV•	Load current
RUN• FWD• REV•	Forward command
RUN• FWD• REV•	Reverse command
RUN• FWD• REV•	Displays the selected parameter
RUN• FWD• REV•	Display the parameter value
RUN• FWD• REV•	Display the external fault

RUN• FWD• REV•	88	If the "End" message (as shown in the left figure) is displayed on the display area for about one second, it means that data has been accepted and
		automatically stored in the internal memory
RUN •	• STOP	If the setting data is not accepted or its value exceeds the allowed range, this
REV•	CCC	error message will be displayed





## List of Characters Shown on the Seven-segment Display of the Digital Keypad Panel

Numeric	0	1	2	3	4	5	6	7	8	9
Seven-segment Display	Ü	!	ċ	3	4	5	6	7	8	9
English Letter	А	а	В	С	С	D	d	Е	е	F
Seven-segment Display	R	_	_		C	_	ď	E	_	F
English Letter	f	G	g	Н	h	1	i	J	j	К
Seven-segment Display	_		_	H	h		_	Ü		۲
English Letter	k	L	I	М	m	N	n	0	0	Р
Seven-segment Display	_	L	_		_	_	n		o	P
English Letter	р	Q	q	R	r	S	S	Т	t	U
Seven-segment Display	_	_	9	_		5	_		Ł	
English Letter	u	V	V	W	W	Х	х	Υ	у	Z
Seven-segment Display	_	_	U	_	_	_	_	4	_	-
English Letter	Z									
Seven-segment Display	_									

## 3-2 Machine Adjustment Procedure

Perform the following operation procedure by using the Digital Keypad (KPVJ-LE01/KPV-CE01) or the monitoring software VFD-Explorer

#### Step 1. Enter the motor's parameters

Restore the factory default values by setting the Parameter 00-02 = 10
 Reset parameter settings

Setting value
of Parameter 10: Reset parameter values
00-02

 Please make sure if the command source has been restored to the factory default (operation by external terminals)

If the KPV-CE01 is used, the Parameter is 01-01=0

Source of operation command

Setting value	0: Operation by using the digital keypad
of Parameter	1: Operation by using the external terminals. The Stop button on the
01-01	keypad is disabled.
	2: Communication using RS-485. The Stop button on the keypad is
	disabled

If the VFD-Explorer is used, the Parameter is 01-01=2

Source of operation command

Setting value	0: Operation by using the digital keypad
of Parameter	1: Operation by using the external terminals. The Stop button on the
01-01	keypad is disabled.
	2: Communication using RS-485. The Stop button on the keypad is
	disabled

Change the display type from Frequency command (Hz) into Speed (rpm)

Display the speed (rpm) defined by the user

Setting value
of Parameter 0~39999rpm
00-06

■ Set the Parameter 01-02

Motor's maximum operation frequency

Setting value	
of Parameter	50.00 – 600.00Hz
01-02	

■ Set the Parameter 01-03

Motor's rated frequency

Setting value

of Parameter 0.00 - 600.00Hz

01-03

Set the Parameters 01-05 & 01-06

Acceleration time setting

Setting value

of Parameter 0.00 – 600.00 seconds

01-05

Deceleration time setting

Setting value

of Parameter 0.00 – 600.00 seconds

01-06

The settings for the induction and synchronous motors are different. Please configure these parameters according to the related adjustment method for the motor.

### Induction motor

■ Set the Parameter 01-00 = 0

Control mode

Setting value 0: VF

of Parameter 1: Reserved 01-00 2: Reserved

3: FOC vector control + Encoder (FOCPG)

4: Reserved5: FOCPM6: Reserved

■ Set the Parameter 01-26 = 0

Encode type

Setting value 0: ABZ

of Parameter 1: ABZ+HALL (only used for Delta's servo motors)

01-26 2: ABZ+HALL 3:Resolver

Set the Parameter 01-29

Number of pulses for each revolution of the encoder

Setting value

of Parameter 1~20000

01-29

Set the Parameter 01-08

The rated current of the induction motor

Setting value
of Parameter 0~655.35 Amps
01-08

Set the Parameter 01-09

The rated power of the induction motor

Setting value of Parameter 0.00 – 655.35kW 01-09

Set the Parameter 01-10

The rated speed (rpm) of the induction motor

Setting value
of Parameter 0~65535
01-10

Set the Parameter 01-11

Number of poles of the induction motor

Setting value
of Parameter 2~20
01-11

- Check if the motor can be separated from the pump
  - If it can be separated, set the Parameter 01-07 as 1 and carry out a dynamic measurement
  - 2. If it cannot be separated, open the safety valve, enter the no-load current of the induction motor 01-12 and set the Parameter 01-07 as 2. Then carry out the static measurement

#### Motor Parameter Auto Tuning

Setting
value of
Parameter
0: No function
1: Rolling test for induction motor(IM) (Rs, Rr, Lm, Lx, no-load current)
2: Static test for induction motor(IM)
3: Reserved
4: Auto measure the angle between magnetic pole and PG origin
5: Rolling test for PM motor

- During the automatic measurement process of the induction motor, the digital keypad will show the message "tun". After the measurement is finished, the motor automatically shuts down, and the measurement values are stored into Parameters 01-13 to 01-16. If the digital keypad shows "AUE", please check if the wiring is correct and if the parameters are set correctly.
- The machine will shut off the power and then supply the power again

■ Set the Parameter 01-00 = 3

#### Control mode

Setting value 0: VF
of Parameter 1: Reserved
01-00 2: Reserved
3: FOC vector control + Encoder (FOCPG)
4: Reserved
5: FOCPM
6: Reserved

Test run

When the motor is in a no-load state, the speed command is set to 10 rpm for low-speed test run. Make sure that the output current value is close to the no-load current.

If no error occurs, gradually increase the value of speed command to the highest speed.

Make sure that the pump's oil supply direction is the forward direction of the motor.

### Synchronous motor

■ Set the Parameter 01-00 = 5

#### Control mode

Setting value 0: VF
of Parameter 1: Reserved
01-00 2: Reserved
3: FOC vector control + Encoder (FOCPG)
4: Reserved
5: FOCPM
6: Reserved

■ Set the Parameter 01-26 = 3

#### Encode type

Setting value 0: ABZ
of Parameter 1: ABZ+HALL (only used for Delta's servo motors)
01-26 2: ABZ+HALL
3:Resolver

Set the Parameter 01-29

Number of pulses for each revolution of the encoder

Setting value	
of Parameter	1~20000
01-29	

Set the Parameter 01-17

The rated current of the synchronous motor

Setting value
of Parameter 0~655.35 Amps
01-17

■ Set the Parameter 01-18

The rated power of the synchronous motor

Setting value
of Parameter 0.00 – 655.35kW
01-18

Set the Parameter 01-19

The rated speed (rpm) of the synchronous motor

Setting value
of Parameter 0~65535
01-19

Set the Parameter 01-20

Number of poles of the synchronous motor

Setting value
of Parameter 2~20
01-20

Set the Parameter 01-21

The inertia of the synchronous motor's rotor

Setting value
of Parameter 0.0~6553.5 \*10<sup>-4</sup> kg.m<sup>2</sup>
01-21

- Check if the motor can be separated from the pump
- If it can be separated, set the Parameter 01-07 as 5 and carry out the parameter measurement of the synchronous motor
- If it cannot be separated, open the safety valve, set the Parameter 01-07 as 5 and carry out the parameter measurement of the synchronous motor

#### Motor Parameter Auto Tuning

Setting value 0: No function
of Parameter 1: Rolling test for induction motor(IM) (Rs, Rr, Lm, Lx, no-load current)
01-07 2: Static test for induction motor(IM)
3: Reserved
4: Auto measure the angle between magnetic pole and PG origin
5: Rolling test for PM motor

During the automatic measurement process of the synchronous motor, the digital keypad will show the message "tun". After the measurement is finished, the motor automatically shuts down, and the measurement values are stored into Parameters 01-22 to 01-25. If the digital keypad shows "AUE", please check if the wiring is correct and if the parameters are set correctly.

■ Set the value of Parameter 01-07 as 4 and press [Run]. When the operation is complete, the PG offset angle of PM motor is written to Parameter 01-27

Motor Parameter Auto Tuning

Setting value 0: No function
of Parameter 1: Rolling test for induction motor(IM) (Rs, Rr, Lm, Lx, no-load current)
01-07 2: Static test for induction motor(IM)
3: Reserved
4: Auto measure the angle between magnetic pole and PG origin
5: Rolling test for PM motor

- The machine will shut off power and then supply power again
- Test run

When the motor is in a no-load state, the speed command is set to 10 rpm for low-speed test run. Make sure that the output current value is close to the zero current.

If no error occurs, gradually increase the value of speed command to the highest speed.

Make sure that the pump's oil supply direction is the forward direction of the motor.

### Step 2. Estimation of Inertia

- Set the speed command as 1000 rpm
- Set the Parameters 01-05 & 01-06 = 0.3~0.5 seconds

Acceleration time setting

Setting value
of Parameter 0.00 – 600.00 seconds
01-05

Deceleration time setting

Setting value
of Parameter 0.00 – 600.00 seconds
01-06

Set the Parameter 01-31 = 2 and then press [Run]

System control

Setting value 0: No function
of Parameter 1: ASR automatic tuning
01-31 2: Estimation of inertia

Check if the value of Parameter 01-32 is converged. If it is converged, stop the operation. If not, switch the rotation direction after the speed is stable.

The unity value of the system inertia

Setting value
of Parameter 1~65535 (256 = 1 per unit)
01-32

- After the operation stops, select the Parameter 01-32 and press the [PROG/DATA] button to complete the "write" operation.
- Set Parameter 01-31=1 and the estimation of the motor's inertia is complete.

## Step 3. Connect the motor and the pump and then confirm the pressure feedback signal

Set the Parameter 00-04 = 11 and then supply voltage to PO

Selection of multi-function display

Setting value of Parameter 00-04

11: display the signal value of the analog input terminal PO with 0~10V

mapped to 0~100%

Parameter 00-08 = related pressure setting value of the pressure sensor at 10V
 Maximum pressure feedback value

Setting value

of Parameter 0~250Bar

80-00

Set the speed command as 10rpm and press [RUN] to confirm if the pressure value through the pressure gauge > 0.

If the pressure value  $\leq 0$ 

- ☑ Gradually increase the rotation speed
- ☑ Confirm the operation direction of the pump
- Make sure that the direction valve is in the close state

If the pressure value > 0

Make sure the multi-function display on the keypad panel shows the voltage indicating the same pressure as the pressure gauge

Example: If the pressure sensors indicates 250bar at 10V, when the pressure gauge shows 50 bar, the pressure sensor output voltage should be around 50/250 \* 10 = 2V, and the voltage shown on the keypad panel should be 20.0 (%)

Observe if there is oil leakage.

#### Step 4. Confirm the pressure command and flow command

Parameter 00-09 = 1 for pressure control mode

Pressure control mode

Setting value

0: Speed control

of Parameter

1: Pressure control

00-09

■ Parameter 00-04 = 12 PI for input voltage

Selection of multi-function display

Setting value

of Parameter

12: display the signal value of the analog input terminal PI with 0~10V

00-04

mapped to 0~100%

Parameter 00-07 = related pressure value of the pressure command at 10V
 Maximum pressure command

Setting value

of Parameter 0~250Bar

00-07

- Send the maximum pressure command through the controller and then check the multi-function display page to enter this value into Parameter 00-14
- Send a half pressure command through the controller and then check the multi-function display page to enter this value into Parameter 00-15
- Send the minimum pressure command through the controller and then check the multi-function display page to enter this value into Parameter 00-16

Example: If the pressure sensor indicates 250bar at 10V. If the maximum pressure on the controller is 140bar and corresponds to 10V, then Parameter 00-07=140. Set the pressure as 140bar through the controller, the voltage value shown on the display is about 56.0 (140/250 \* 100%). Enter this value into the Parameter 00-14. Then set the pressure as 70bar on the controller, and now the value displayed on the keypad panel is about 28.0 (70/250 \* 100%). Enter this value to the Parameter 00-15. Then set the pressure as 0 bar on the controller, and the voltage value shown on the display is about 0.0 (0/250 \* 100%). Enter this value in the Parameter 00-16.

■ Parameter 00-04 = 25 for QI input voltage

Selection of multi-function display

Setting value of Parameter 00-04

25: display the signal value of the analog input terminal OI with 0~10V

mapped to 0~100%

Send the 100% flow rate through the controller and then check the multi-function display page to enter this value into Parameter 00-17

- Send the 50% flow rate through the controller and then check the multi-function display page to enter this value into Parameter 00-18
- Send the 0% flow rate through the keypad panel and then check the multi-function display page to enter this value into 00-19

Step 5. Bleed the circuit and make sure if there is any plastic material in the barrel. The machine can start operation only when there are no plastic materials inside the barrel.

■ Parameter 00-09 = 1 for pressure control mode

Pressure control mode

Setting value

0: Speed control

of Parameter

1: Pressure control

00-09

Set the Parameters 01-05 & 01-06 = 0 second
 Acceleration time setting

Setting value
of Parameter 0.00 – 600.00 seconds
01-05

#### Deceleration time setting

Setting value
of Parameter 0.00 – 600.00 seconds
01-06

- For low-pressure and low-speed conditions (within 30% of the rated values), use the "manual operation" through the controller for the operation of each cylinder. During the operation, check the pipe connection for leaks or strange noise in the pump.
- When the air is bleeding completely, if there is any pressure fluctuation during operation, please adjust the pressure control Parameter PI in accordance with the method described in the "Description of Parameters".

#### Step 6. Send operation command though the controller

Parameter 01-01=1

Source of operation command

Setting value	0: Operation by using the digital keypad
of Parameter	1: Operation by using the external terminals. The Stop button on the
01-01	keypad is disabled.
	2: Communication using RS-485. The Stop button on the keypad is
	disabled

#### Step 7. Adjustment for injection/pressure holding

- Heat up the barrel to the required temperature and set the controller in manual control mode.
- Set the Ki values for the three stages PI to 0 (Parameters 00-21, 00-23, and 00-25) and Kp values to small values ( $\leq$ 50.0)
- Start the plastic injection operation. The "Target value" is low pressure (<50Bar) and low flow rate (<30%)  $^{\circ}$
- Press the "injection" button on the operation panel for the injection operation or the machine will enter the pressure holding operation (depending on the position of the cylinder)
- In the pressure holding state, use the software (VFD-Explorer) to observe the waveform. Without causing the vibration of the motor, increase the speed bandwidth to the maximum value 40Hz (Parameter 00-10).
- In the pressure holding condition, if the pointer of the pressure gauge or the monitored pressure waveform has no fluctuation, it means that the pressure is stably fed back. It is allowed to increase the three Kp values.

- When the pressure feedback becomes unstable, reduce the three Kp values by 20% (example: the three Kp values are reduced from 100.0 to 80.0). Adjust the three Ki values to eliminate the steady-state error so as to speed up system response.
- When the above steps are completed, increase the "target value" for the pressure command.
- Observe if the pressure feedback is stable. If there is an abnormal condition, please solve it as follows:

#### Solve the pressure instability problem


#### Instability at high pressure

If the Hybrid servo drive has an overload condition, please increase the power rating of the Hybrid servo drive

#### Instability over the entire pressure range

- 1. Set Parameter 00-09 = 0 to switch to the speed control
- 2. If the hydraulic circuit is in the closed state, send a low speed command so as to allow a pressure feedback value of 40-50% of the value for pressure command (parameters 00-07)
- **3.** By using the monitoring software, observe if the pressure waveform has irregular fluctuations.
  - Pressure waveform fluctuates It may be a ground interference problem. If the motor or the three-phase power supply is grounded, disconnect the ground wire. If the motor or three-phase power supply has no ground wire, you can install a ground wire for anti-interference protection.

It may be a grounding problem of the shield mesh (as the red thick line shown below). If the shield mesh is properly grounded, the ground wire can be removed; if the shield mesh has no grounding wire, install a ground wire for anti-interference protection.



4. If there is any abnormal condition that can not be solved, please contact the manufacturer.

### Step 8. Adjustment of system transient response

- Reduce the pressure rise time, increase Kp1 (Parameter 00-20) and reduce the Ki1 time (Parameter 00-21)
- For pressure overshoot, increase the Kp3 time (Parameter 00-24) and reduce the Ki3 time (Parameter 00-25)

## **Confluence Machine Tuning Procedure**

Wiring according to Chapter 2

Carry out the automatic measurement of the motor's parameters according to Step 1 and Step 2 described above for the Master and Slave, respectively. Then perform the following procedure

#### Master setting

Set the Parameter 03-06 = 1
 Multifunction Output 2 (MO1)

Setting value
of Parameter 1: Operation indication
03-06

- Connect the Master's MO1 output terminal to the Slave's SON terminal and Master's MCM terminal to the Salve's COM terminal.
- For the firmware version 2.03 and above, it is not necessary to perform the two steps described above
- Set the Parameter 03-13 = 1

Confluence Master/Slave Selection

Setting value 0: No function
of Parameter 1: Master 1
03-13 2: Slave/Master 2
3: Slave/Master 3

Set the Parameter 03-14

Slave's proportion of the Master's flow

Setting value of Parameter 0.0~6553.5% 03-14

■ For firmware version 2.03 and above, the Parameter 03-17 can be configured to determine the activation level for the Slave

Slave's activation level

Setting value
of Parameter 0~100%
03-17

### Slave setting

■ Parameter 01-01=1

Source of operation command

Setting value	0: Operation by using the digital keypad
of Parameter	1: Operation by using the external terminals. The Stop button on the
01-01	keypad is disabled.
	2: Communication using RS-485. The Stop button on the keypad is
	disabled

■ For firmware version 2.03 and above, set the Parameter 01-01=2

Source of operation command

Setting value	0: Operation by using the digital keypad
of Parameter	1: Operation by using the external terminals. The Stop button on the
01-01	keypad is disabled.
	2: Communication using RS-485. The Stop button on the keypad is
	disabled

Set the Parameter 03-15 = 1

Source of Frequency Command

Setting value	0: Digital Operation Panel
of Parameter	1: RS485 Communication
03-15	2~5: reserved

Shut down the power and then supply the power again

Set an arbitrary value of the frequency command at the Master to check if the Slave has the same value of the frequency command

Set 10rpm at the Master and then press RUN to see if the Slave is also running. If not, check the wiring or the parameter setting for any problem

Set the Slave Parameter 03-13 = 2

Confluence Master/Slave Selection

Setting value	0: No function
of Parameter	1: Master 1
03-13	2: Slave/Master 2
	3: Slave/Master 3

For firmware version 2.03 and above, the Parameter 03-21 can be set at the Slave to decide if the Salve is performing the reversed operation for depressurization.

Note: If it is required to reverse the operation for depressurization at the Slave, it is necessary to make sure that the pump outlet port is not installed with a check valve and the Parameter 03-16 should be set as 500%

Slave reverse operation for depressurization

Setting value 0: Disable of Parameter 1: Enable 03-21

Limit for the Slave reverse depressurization torque

Setting value 0~500% of Parameter 03-16

 Shut off the power and the re-supply power for the Slave, and then set the Slave in the speed control mode

Speed Control Mode

Setting value 0: Speed control of Parameter 1: Pressure control 00-09

In this case, the Master can be tuned according to the Step 3 – Step 8 described above

# Confluence/Diversion Mode Adjustment Procedure

Wiring according to Chapter 2

In a diversion condition, adjust various parameters of the Hybrid servo drive according to the Step 1 – Step 8 describe above

In a confluence condition, please refer to the machine adjustment procedure for the confluence operation

Complete the above steps

Set the Master for pressure control mode

■ Parameter 00-09 = 1 for pressure control mode

Pressure control mode

Setting value 0: Speed control
of Parameter 1: Pressure control
00-09

Set the Slave for speed control mode

Parameter 00-09 = 0 for speed control mode

Speed Control Mode

Setting value 0: Speed control
of Parameter 1: Pressure control
00-09

Respectively set the master/slave multi-function input state. For the firmware version 2.03 and above, it is necessary to set these parameters for the Slave only

■ Parameter 03-00~03-02 = 45 confluence/diversion signal input Multi-function Input

Setting values
of Parameters
03-00~03-02

0: No function
45: Confluence/Diversion signal input

■ Through the controller, perform the entire confluence/diversion operation.

## 4. Description of Parameters

- 4-1 Summary of Parameters
- 4-2 Detailed Description of Parameters

## **4-1 Summary of Parameters**

## **00 System Parameters**

★ the parameter can be set during oper ation

		auon				
Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
00-00	Hybrid servo drive model code ID	12: 230V, 7.5HP 13: 460 V, 7.5HP 14: 230V, 10HP 15: 460V, 10HP 16: 230V, 15HP 17: 460V, 15HP 18: 230V, 20HP 19: 460V, 20HP 20: 230V, 25HP 21: 460V, 25HP 22: 230V, 30HP 23: 460V, 30HP 24: 230V, 40HP 25: 460V, 40HP 26: 230V, 50HP 27: 460V, 50HP 29: 460V, 60HP 31: 460V, 75HP 33: 460V, 100HP	Read only	0	0	0
00-01	Display of rated current of the Hybrid servo drive	Display the model specific values	Read only	0	0	0
00-02	Reset parameter settings	5: Rest the kWh at drive stop 10: Reset parameter values	0	0	0	0
00-03	Software version	Read only	Read only	0	0	0

P	arameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
~	Selection of multi-function display		0: Display the output current (A) 1: Reserved 2: Display the actual output frequency (H) 3: Display the DC-BUS voltage (U) 4: Display the output voltage (E) 5: Display the output power angle (n) 6: Display the output power in kW (P) 7: Display the actual motor speed rpm (r) 8: Display the estimated output torque (%) 9: Display the PG feedback (G) 10: Reserved 11: Display the signal value of the analog input terminal PO % (1.) 12: Display the signal value of the analog input terminal PI % (2.) 13: Display the signal value of the analog input terminal AUI % (3.) 14: Display temperature of the heat sink in °C (t.) 15: Display temperature of IGBT in °C (T) 16: The status of digital input (ON/OFF) (i) 17: The status of digital output (ON/OFF) (o) 18: Reserved 19: The corresponding CPU pin status of the digital input (i.) 20: The corresponding CPU pin status of the digital output (o.) 21~24: Reserved 25: Display the signal value of the analog input terminal QI % (5.) 26: Display the actual pressure value (Bar) (b.) 27: Display the motor temperature (currently only support KTY84) (T.)	0	0	0	0
~	00-05	Analog output function selection	0: Output frequency (Hz)	0	0	0	0
			1: Frequency command (Hz)		0	0	0
			2: Motor speed (Hz)		0	0	0
			3: Output current (A)			0	0
			4: Output voltage		0	0	0
			5: DC Bus voltage		0	0	0
			6: Power factor 7: Power 8: Output torque 9: PO 10: PI 11: AUI 12~20: Reserved		0	0	0
	00-06	Display the speed (rpm) defined by the user	0~39999 rpm	0	0	0	0
~	00-07	Maximum value for the pressure command	0~250 Bar	250	0	0	0
~	80-00	Maximum pressure feedback value	0~400 Bar	250	0	0	0

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
	00-09	Pressure control mode	Speed control     Pressure control	0	0	0	0
	00-10	Speed bandwidth	0~40Hz	20		0	0
×	00-11	Pressure feedback filtering time PO	0.000~1.000 second	0.000	0	0	0
N	00-12	Pressure command filtering time PI	0.000~1.000 second	0.000	0	0	0
×	00-13	Flow command filtering time QI	0.000~1.000 second	0.000	0	0	0
×	00-14	Percentage for the pressure command value (Max)	0.0~100.0%	100.0	0	0	0
N	00-15	Percentage for the pressure command value (Mid)	0.0~100.0%	50.0	0	0	0
×	00-16	Percentage for the pressure command value (Min)	0.0~100.0%	0.0	0	0	0
×	00-17	Percentage for the flow command value (Max)	0.0~100.0%	100.0	0	0	0
×	00-18	Percentage for the flow command value (Mid)	0.0~100.0%	50.0	0	0	0
×	00-19	Percentage for the flow command value (Min)	0.0~100.0%	0.0	0	0	0
N	00-20	P gain 1	0.0~1000.0	50.0	0	0	0
N	00-21	I integration time 1	0.00~500.00 seconds	2.00	0	0	0
N	00-22	P gain 2	0.0~1000.0	50.0	0	0	0
N	00-23	I integration time 2	0.00~500.00 seconds	2.00	0	0	0
N	00-24	P gain 3	0.0~1000.0	50.0	0	0	0
N	00-25	I integration time 3	0.00~500.00 seconds	2.00	0	0	0
N	00-26	Pressure stable region	0~100%	25	0	0	0
N	00-27	Base pressure	0.0~100.0%	1.0	0	0	0
N	00-28	Depressurization speed	0~100%	25	0	0	0
×	00-29	Ramp up rate of pressure command	0~1000ms	0	0	0	0
×	00-30	Ramp down rate of pressure command	0~1000ms	100	0	0	0
×	00-31	Ramp up rate of flow command	0~1000 ms	80	0	0	0
×	00-32	Ramp down rate of flow command	0~1000 ms	80	0	0	0

### 4. Description of Parameters

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
×	00-33	Valve opening delay time	0~200 ms	0	0	0	0
	00-34	Reserved					
×	00-35	Over-pressure detection level	0~250 Bar	230	0	0	0
×	00-36	Detection of disconnection of pressure feedback	<ul><li>0 : No function</li><li>1: Enable (only for the pressure feedback output signal within 1~5V)</li></ul>	0	0	0	0
×	00-37	Differential gain	0.0~100.0 %	0.0	0	0	0
	00-38	Pressure/flow control function selection	Bit 0: 0: Switch the PI Gain according to the pressure feedback level  1: Switch the PI Gain according to the multi-function input terminal  Bit 1: 0: No pressure/flow control switch  1: Switch between the pressure and flow control	0	0	0	0

## **01 Motor Parameters**

## ★ the parameter can be set during operation

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
			0: VF				
			1: Reserved				
			2: Reserved				
	01-00	Control mode	3: FOCPG	5	0	0	0
			4: Reserved				
			5: FOCPM				
			6: Reserved				
			0: Operation by using the digital keypad				
		Source of operation	1: Operation by using the external terminals. The Stop button				
×	01-01	command	on the keypad is disabled.	1	0	0	0
			2: Communication using RS-485. The Stop button on the				
			keypad is disabled				
	01-02	Motor's maximum operation frequency	50.00~600.00Hz	60.00/ 50.00	0	0	0
	01-03	Motor's rated frequency	0.00~600.00Hz	60.00/ 50.00	0	0	0
			230V Series: 0.1V~255.0V	220.0			
	01-04	Motor's rated voltage	460V Series: 0.1V~510.0V	440.0	0	0	
×	01-05	Acceleration time setting	0.00~600.00 seconds	0.00	0	0	0
~	01-06	Deceleration time setting	0.00~600.00 seconds	0.00	0	0	0
	01-07	Motor Parameter Auto Tuning	0: No function	0	0	0	
			1: Rolling test for induction motor(IM) (Rs, Rr, Lm, Lx, no-load current)		0	0	
			2: Static test for induction motor(IM)		0	0	
			3: Reserved		0	0	
			4: Auto measure the angle between magnetic pole and PG				
			origin				0
			5: Rolling test for PM motor				0
		Rated current of the induction					
	01-08	motor (A)	40~120% of the drive's rated current	#.##		0	
×	01-09	Rated power of the induction motor	0~655.35kW	#.##		0	
		Rated speed of the induction	0~65535rpm				
*	01-10	motor	1710 (60Hz 4-pole); 1410 (50Hz 4-pole)	1710		0	
		Number of poles of the					
	01-11	induction motor	2~20	4		0	

Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
01-12	No-load current of the induction motor (A)	0~Default value of Parameter 01-08	#.##		0	
01-13	Stator resistance (Rs) of the induction Motor	0~65.535Ω	#.###		0	
01-14	Rotor resistance (Rr) of the induction Motor $0\sim65.535\Omega$		#.###		0	
01-15	Magnetizing inductance (Lm) of the induction Motor	0.0~6553.5mH	#.#		0	
01-16	Total leakage inductance (Lx) of the induction motor	0.0~6553.5mH	#.#		0	
01-17	Rated current of the synchronous motor	0~655.35 Amps	0.00			0
01-18	Rated power of the synchronous motor	0.00 – 655.35kW	0.00			0
01-19	Rated speed of the synchronous motor	0~65535rpm	0			0
01-20	Number of poles of the synchronous motor	2~20	6			0
01-21	Inertia of the synchronous motor's rotor	0.0~6553.5 *10 <sup>-4</sup> kg.m <sup>2</sup>	0.0			0
01-22	Stator's phase resistance (Rs) of the synchronous motor	0.000~65.535Ω	0.000			0
01-23	Stator's phase inductance (Ld) of the synchronous motor	0.00.0~655.35mH	0.00			0
01-24	Stator's phase inductance (Lq) of the synchronous motor	0.00.0~655.35mH	0.00			0
01-25	Back EMF of the synchronous motor	0~65535 V/krpm	0			0
01-26	Encode type	0: ABZ 1: ABZ+HALL (only used for Delta's servo motors) 2: ABZ+HALL 3: Resolver	3			0
01-27	PG Offset angle of synchronous motor	0.0~360.0°	0.0			0

Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
01-28	Number of poles of the resolver	1~5	1			0
01-29	Encoder pulse	1~20000	1024		0	0
01-30	Encoder's input type setting	0: No function  1: Phase A leads in a forward run command and phase B leads in a reverse run command  2: Phase B leads in a forward run command and phase A leads in a reverse run command			0	0
01-31	System control	0: No function 1: ASR automatic tuning 2: Estimation of inertia	1		0	0
01-32	Unity value of the system inertia	1~65535 (256 = 1 per unit)	400		0	0
01-33	Carrier frequency	5KHz; 10KHz	5	0	0	0
01-34	Reserved					
01-35	Motor ID	0 : No function  16: Delta's Hybrid servo motor ECMA-ER181BP3 (11kW220V)  17: Delta's Hybrid servo motor ECMA-KR181BP3 (11kW380V)  18: Delta's Hybrid servo motor ECMA-ER221FPS (15kW220V)  19: Delta's Hybrid servo motor ECMA-KR221FPS (15kW380V)  21: Delta's Hybrid servo motor ECMA-KR222APS (20kW380V)	0	0	0	0
01-36	Change the rotation direction	<ul> <li>0: When the driver runs forward, the motor rotates counterclockwise. When the driver runs reverse, the motor rotates clockwise.</li> <li>1: When the driver runs forward, the motor rotates clockwise. When the driver runs reverse, the motor rotates counterclockwise</li> </ul>	0	0	0	0

## **0-2 Parameters for Protection**

## ★ the parameter can be set during operation

		operation				
Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
02-00	Software brake level	230V series: 350.0~450.0Vdc	380.0	0	0	0
02-00	Software brake level	460V series: 700.0~900.0Vdc	760.0			
02-01	Present fault record	0: No error record	0	0	0	0
02-02	Second most recent fault record	1: Over-current during acceleration (ocA)	0	0	0	0
02-03	Third most recent fault record	2: Over-current during deceleration (ocd)	0	0	0	0
02-04	Fourth most recent fault record	3: Over-current during constant speed (ocn)	0	0	0	0
02-05	Fifth most recent fault record	4: Ground fault (GFF)	0	0	0	0
02-06	Sixth most recent fault record	5: IGBT short-circuit (occ)	0	0	0	0
		6: Over-current at stop (ocS)		0	0	0
		7: Over-voltage during acceleration (ovA)		0	0	C
		8: Over-voltage during deceleration (ovd)		0	0	
		9: Over-voltage during constant speed (ovn)		0	0	
		10: Over-voltage at stop (ovS)		0	0	
		11: Low-voltage during acceleration (LvA)		0	0	
		12: Low-voltage during deceleration (Lvd)		0	0	
		13: Low-voltage during constant speed (Lvn)		0	0	
		14: Low-voltage at stop (LvS)		0	0	
		15: Phase loss protection (PHL)		0	0	
		16: IGBT over-heat (oH1)		0	0	
		17: Heat sink over-heat for 40HP and above (oH2)		0	0	
		18: TH1 open: IGBT over-heat protection circuit error (tH1o)		0	0	(
		19: TH2 open: heat sink over-heat protection circuit error (tH2o)		0	0	
		20: Fan error signal output (Fan)		0	0	
		21: Hybrid servo drive overload (oL)		0	0	
		22: Motor over-load (EoL1)		0	0	
		23: Reserved				
		24: Motor over-heat, detect by PTC (oH3)		0	0	
		25: Reserved				
		26: Over-torque 1 (ot1)		0	0	

Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
		27: Over-torque 2 (ot2)		0	0	0
		28: Reserved		0	0	0
		29: Reserved		0	0	0
		30: Memory write error (cF1)		0	0	0
		31: Memory read error (cF2)		0	0	0
		32: Isum current detection error (cd0)		0	0	0
		33: U-phase current detection error (cd1)		0	0	0
		34: V-phase current detection error (cd2)		0	0	0
		35: W-phase current detection error (cd3)		0	0	0
		36: Clamp current detection error (Hd0)		0	0	0
		37: Over-current detection error (Hd1)		0	0	0
		38: Over-voltage detection error (Hd2)		0	0	0
		39: Ground current detection error (Hd3)		0	0	0
		40: Auto tuning error (AuE)			0	0
		41: Reserved		0	0	0
		42: PG feedback error (PGF1)			0	0
		43: PG feedback loss (PGF2)			0	0
		44: PG feedback stall (PGF3)			0	0
		45: PG slip error (PGF4)			0	0
		46: Reserved		0	0	0
		47: Reserved		0	0	0
		48: Reserved				
		49: External fault input (EF)		0	0	0
		50: Emergency stop (EF1)		0	0	0
		51: Reserved				
		52: Password error(PcodE)		0	0	0
		53: Reserved		0	0	0
		54: Communication error (cE1)		0	0	0
		55: Communication error (cE2)		0	0	0
		56: Communication error (cE3)		0	0	0
		57: Communication error (cE4)		0	0	0
		58 : Communication time out (cE10)		0	0	0
		59: PU time out (cP10)		0	0	0
		60: Braking transistor error (bF)		0	0	0
		61~63: Reserved		0	0	0
		64: Safety relay Error (SRY)		0	0	0
		65: PG card information error (PGF5)				0
		66: Over pressure (ovP)		0	0	0

### 4. Description of Parameters

	Parameter code	Function of the parameter	Settings	Default value	ΛF	FOCPG	FOCPM
			67: Pressure feedback fault (PfbF)		0	0	0
	02-07	Low voltage lovel	160.0~220.0Vdc	180.0			
7	02-07	Low voltage level	320.0.0~440.0Vdc	360.0	0	0	0
			0: Warn and keep operation				
×	02-08	PTC action selection	1: Warn and ramp to stop	0	0	0	0
			2: Warn and coast to stop				
N	02-09	PTC level	0.0~150.0%	50.0	0	0	
^	02-03	1 TO ICVCI	0.0~150.0℃	30.0	O		
×	02-10	PTC detection filtering time	0.00~10.00 seconds	0.20	0	0	0
×	02-11	PTC type	0: Not assigned	0	0	0	
^	02-11	i i o type	1: KTY84		0		
<b>₩</b>	02-12	Motor fan activation level	0.0~100.0%	50.0	0	0	
^	02-12	inotor fair activation level	0.0~150.0℃	30.0	0		
		Electronic thermal relay	0: Inverter motor				
×	02-13	selection 1	1: Standard motor	2	0	0	0
		Sciedion 1	2: Disable				
*	02-14	Electronic thermal characteristic for motor	30.0~600.0 seconds	60.0	0	0	0
	02-15	Output frequency at malfunction	0.00~655.35 Hz	Read only	0	0	0
	02-16	Output voltage at malfunction	0.0~6553.5 V	Read only	0	0	0
	02-17	DC voltage at malfunction	0.0~6553.5 V	Read only	0	0	0
	02-18	Output current at malfunction	0~655.35 Amps	Read only	0	0	0
	02-19	IGBT temperature at malfunction	0.0~6553.5 °C	Read only	0	0	0

## **03 Digital/Analog Input/Output Parameters** *✓* the parameter can be set during operation

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
	03-00	Multi-function input	0: No function	0	0	0	0
		command 3 (MI3)	44: Injection signal input			Ŭ	
	03-01	Multi-function input	45: Confluence/Diversion signal input	0	0	0	0
	00 01	command 4 (MI4)	46: Reserved				
	03-02	Multi-function input	47: Multi-level pressure PI command 1	0	0	0	0
		command 5 (MI5)	48: Multi-level pressure PI command 2				
*	03-03	Digital input response time	0.001~ 30.000 sec	0.005	0	0	0
*	03-04	Digital input operation direction	0~65535	0	0	0	
~	03-05	Multi-function output 1	0: No function	11	0	0	0
-		(Relay 1)	1: Operation indication				
$_{\prime\prime}$	03-06	Multi-function Output 2	9: Hybrid servo drive is ready	0	0	0	0
-		(MO1)	11: Error indication				
$_{\prime}$	03-07	Multi-function Output 3	44: Displacement switch signal	0	0	0	0
-		(MO2)	45: Motor fan control signal				
*	03-08	Multi-function output direction	0~65535	0		0	
*	03-09	Low-pass filter time of keypad display	0.001~65.535 seconds	0.010	0	0	0
	03-10	Maximum output voltage for pressure feedback	5.0~10.0 V	10.0	0	0	0
	03-11	Minimum output voltage for pressure feedback	0.0~10.0 V	0.0	0	0	0
*	03-12	Reserved					
			0: No function				
	03-13	Confluence Master/Slave	1: Master 1				
	03-13	Selection	2: Slave/Master 2	0	0	0	0
			3: Slave/Master 3				
	03-14	Slave's proportion of the Master's flow	0.0~65535.5 %	100.0	0	0	0
		Course of fee	0: Digital keypad				
*	03-15	Source of frequency	1: RS485 Communication	0	0	0	0
		command	2~5: Reserved				
*	03-16	Limit for the Slave reverse depressurization torque	0~500%	20	0	0	0
*	03-17	Slave's activation level	0.0~100.0%	50.0	0	0	0

#### 4. Description of Parameters

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
×	03-18	Communication error	<ul><li>0: Warn and keep operation</li><li>1: Warn and ramp to stop</li><li>2: Warn and coast to stop</li><li>3: No action and no display</li></ul>	3	0	0	0
×	03-19	Time-out detection	0.0~100.0 seconds	0.0	0	0	0
N	03-20	Start-up display selection	0: F (frequency command)  1: H (actual frequency)  2: Multi-function display (user-defined 00-04)  3: A (Output current)	0	0	0	0
×	03-21	Slave reverse operation for depressurization	0: Disabled 1: Enabled	0	0	0	0

## 4-2 Detailed Description of Parameters

## 00 System Parameters

\* the parameter can be set during opera tion

## ## Hybrid servo drive model code ID

Control mode VF FOCPG FOCPM Factory default: Read only

Settings Read only

## **GG-G** Display of rated current of the Hybrid servo drive

Control mode VF FOCPG FOCPM Factory default: Read only

Settings Read only

Parameter 00-00 is used to determine the capacity of the Hybrid servo motor which has been configured in this parameter in factory. In addition, the current value of Parameter (00-01) can be read out to check if it is the rated current of the corresponding model. Display value of the current value of Parameter 00-01 for the related Parameter 00-00.

230V Series								
Power (KW)	5.5	7.5	11	15	18.5	22	30	37
Horse Power (HP)	7.5	10	15	20	25	30	40	50
Model ID	12	14	16	18	20	22	24	26

460V Series											
Power (KW)	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Horse Power (HP)	7.5	10	15	20	25	30	40	50	60	75	100
Model ID	13	15	17	19	21	23	25	27	29	31	33

## ## Reset parameter settings

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: No function

5: Rest the kWh at drive stop10: Reset parameter values

If it is necessary to restore the parameters to factory default, just set this parameter to "10".

## Software version

Control mode VF FOCPG FOCPM Factory default: #.##

Settings Read only

## Selection of multi-function display

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: Display the output current (A)

1: Reserved

2: Display the actual output frequency (H)

"H 538

3: Display the DC-BUS voltage (U)	. 53 103
4: Display the output voltage (E)	. [82883]
5: Display the output power angle (n)	"n <u>88</u>
6: Display the output power in kW (P)	J P8888
7: Display the actual motor speed(r 00: forward speed; - 00: negative speed)	[- 00]
8: Display the estimated output torque (%) (t 0.0: positive torque; - 0.0: negative torque) (%)	. E 0.0
9: Display the PG feedback (G)	. 6 00
<ul> <li>10: Reserved</li> <li>11: Display the signal value of the analog input terminal PO with 0~10V mapped to 0~100%</li> <li>12: Display the signal value of the analog input terminal PI with 0~10V mapped to 0~100%</li> <li>13: Display the signal value of the analog input terminal PI with -10~10V mapped to 0~100%</li> <li>14: Display temperature of the heat sink in °C (t.)</li> <li>15: Display temperature of the IGBT power module °C</li> <li>16: The status of digital input (ON/OFF)</li> <li>17: The status of digital output (ON/OFF)</li> <li>18: Reserved</li> <li>19: The corresponding CPU pin status of the digital input</li> <li>20: The corresponding CPU pin status of the digital output</li> <li>21~24: Reserved</li> </ul>	3. 00 3. 00 4. 00 5. 00 5. 00 5. 00 5. 00 5. 00 5. 00 5. 00
25: Display the signal value of the analog input terminal OI with 0~10V mapped to 0~100%	J 5. 0.0
26: Display the actual pressure value (Bar)	, b. 0.0
27: Display the kWh value	"H 00
28: Display the motor temperature (currently only support KTY84)	, F. <u>88</u>

This parameter defines the contents to be displayed in the U page of the digital keypad KPV-CE01 (as shown in the figure).

## ✓ ₩ ☐ - ₩ ☐ Analog output function selection

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0~20

### **Summary of functions**

Setting Value	Function	Description				
0	Output frequency (Hz)	The maximum frequency is 100%				
1	Frequency command (Hz)	The maximum frequency is 100%				
2	Motor speed (Hz)	600Hz is used as 100%				

3	Output current (A)	2.5 times of the rated current of the Hybrid servo				
		drive is used as 100%				
4	Output voltage	2 times of the rated current of the Hybrid servo drive				
		is used as 100%				
5	DC BUS voltage	450V (900V) =100%				
6	Power factor	-1.000~1.000=100%				
7	Power	Rated power of the drive =100%				
8	Output torque	Rated torque =100%				
9	PO	(0~10V=0~100%)				
10	PI	(0~10V=0~100%)				
11	AUI	(-10~10V=0~100%)				
12~20	Reserved					

## ## Display the speed (rpm) defined by the user

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0~39999 rpm

Set the maximum speed of the motor corresponding to the 100% flow.

## Maximum value for the pressure command

Control mode VF FOCPG FOCPM Factory default: 250

Settings 0~250Bar

The 0~10V for the pressure command on the controller is mapped to 0~the value of this parameter.

## ✓ ☐☐ - ☐☐ Maximum pressure feedback value

Control mode VF FOCPG FOCPM Factory default: 250

Settings 0~400Bar

☐ The 0~10V for the pressure sensor is mapped to 0~the value of this parameter.

### ## Pressure control mode

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: Speed control

1: Pressure control

This parameter determines the control mode of the Hybrid servo drive. It is recommended to use the speed control at the initial start up. After the motor, pump, pressure sensor, and the entire system are checked without any error, switch to the pressure control mode to enter the process control.

## ## Speed bandwidth

Control mode FOCPG FOCPM Factory default: 20

Settings 0~40Hz

Set the speed response. The larger value indicates the faster response.

## Pressure feedback filtering time PO

N	00-13	Pressure	e feedb	ack filterin	ng time QI			
	Control mode	VF F	OCPG F	FOCPM			Factory default: 0.000	
		Settings	0.00	00~1.000 se	econds			
	Noises may reside in the analog input signals of the control terminals PO, PI, and QI. The noise							
	may affect the control stability. Use an input filter to eliminate such noise.							
	If the time constant is too large, a stable control is obtained with poorer control response. If it is to							
	small, a fast response is obtained with unstable control. If the optimal setting is not known, adjust							
	properly according to the instability or response delay.							
N	88-14	Percenta	age for	the pressu	ure command	value (Max)		
×	88-15	Percenta	age for	the pressu	ure command	value (Mid)		
×	88 - 18	Percenta	age for	the pressu	ure command	value (Min)		
	Control mode	VF F	OCPG F	FOCPM			Factory default: 100.0	
		Settings	0.0~	-100.0%				
	To set the	ese param	neters, it	is necessar	ry to set Parame	ter 00-09 as 1		
	Paramet	er 00-04 =	= 12 for F	PI input volta	age			
	Send the	e maximun	n pressu	ire comman	d through the co	ontroller and the	en check the multi-function	
	display page to enter this value into 00-14							
	Send a half pressure command through the controller and then check the multi-function display							
	page to enter this value into 00-15							
	Send the	e minimum	pressur	re command	d through the co	ntroller and the	n check the multi-function	
	display page to enter this value into 00-16							
	Example: If the pressure sensor indicates 250bar at 10V. If the controller's maximum pressure of							
	140bar corresponds to 10V, then Parameter 00-07=140. Set the pressure as 140bar by using							
	the controller, the voltage value shown on the display is about 56.0 (140/250 * 100%). Enter							
	this value into the Parameter 00-14. Then set the pressure as 70bar on the controller, and							
					• .	•	00%). Enter this value to the	
				•			and the voltage value shown	
	on t	the keypac	d is abou	at 0.0 (0/250	) * 100%). Enter	this value in th	e Parameter 00-16.	
N	88- 17	Percenta	age for	the flow c	ommand valu	e (Max)		
×	88 - 88	Percenta	age for	the flow c	ommand valu	e (Mid)		
×	88-19	Percenta	age for	the flow c	ommand valu	e (Min)		
	Control mode	VF F	OCPG F	FOCPM			Factory default: 100.0	
		Settings	0.0	~100.0%				

Pressure feedback filtering time Pl

Send the 50% flow rate through the controller and then check the multi-function display page to enter this value into 00-18


Send the 100% flow rate through the controller and then check the multi-function display page to

☐ To set these parameters, it is necessary to set Parameter 00-09 as 1

Parameter 00-04 = 25 for QI input voltage


enter this value into 00-17

Send the 0% flow rate through the controller and then check the multi-function display page to enter this value into 00-19





Settings

 $0 \sim 100\%$ 



Adjust the Kp value to a proper level first, and then adjust the Ki value (time). If the pressure has overshoot, adjust the kd value.





## 

Control mode VF FOCPG FOCPM Factory default: 1.0

Settings  $0.0 \sim 100.0\%$ 

☐ Set the minimum pressure value 100% corresponding to Parameter 00-08

Typically, it is necessary to maintain a certain base pressure to ensure that the oil pipe is in fully filled condition so as to avoid the activation delay of the cylinder when a pressure/flow command is activated.

## ✓ □□ - ≥□ Depressurization speed

Control mode VF FOCPG FOCPM Factory default: 25

Settings  $0\sim100\%$ 

Set the highest rotation speed at depressurization. The 100% value is mapped to Parameter 01-02 (the maximum rotation speed of the motor)

★ 88 - 29 Ramp up rate of pressure command


Ramp down rate of pressure command

Control mode VF FOCPG FOCPM Factory default: 100

Settings 0~1000ms

Ramp the pressure value for the pressure command so as to reduce the vibration of the machine.

☐ Set the time required for ramping the pressure from 0~the maximum pressure (00-08).



Ramp up rate of flow command

★ 30 - 32 Ramp down rate of flow command


Control mode VF FOCPG FOCPM

Settings 0~1000ms

Factory default: 80

Ramp the flow value for the flow command so as to reduce the vibration of the machine.

Set the time required for ramping the flow from 0~the maximum flow (01-02).




#### 

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0 - 200 ms

When both the pressure command and flow command activate the machine to start from idle, the flow starts to output. However, due to the slower response of the valve in the hydraulic circuit, the sudden surge of the pressure may occur. The pressure may recover to normal till the valve is fully opened. To avoid the aforementioned effect, set this parameter to increase time for the flow output delay.



#### ## Reserved

#### ✓ ☐☐ - 35 Over-pressure detection level

Control mode VF FOCPG FOCPM Factory default: 230

Settings 0~250 Bar

When the pressure feedback exceeds this parameter setting, an "ovP over pressure" error message may occur.

#### ★ ## Detection of disconnection of pressure feedback

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: No function

1: Enable (only for the pressure feedback output signal within 1~5V)

When this parameter is set as 1 and if the pressure feedback signal is below 1V, an "Pfbf pressure feedback fault" error message may occur.

#### ✓ ☐☐ - ☐☐ Pressure/flow control function selection

Control mode VF FOCPG FOCPM Factory default: 0

Bit 0:

Settings 0: Switch the PI Gain according to the pressure feedback level

1: Switch the PI Gain according to the multi-function input terminal

Bit 1:

0: No pressure/flow control switch

1: Switch between the pressure and flow control

When the Bit 0 of this parameter is set as 1, the PI Gain for the pressure can be switched in conjunction with the multi-function input terminal

Multi-function input	Multi-function input	
terminal = 47	terminal = 48	
OFF	OFF	PI1(Parameters 00-20 & 00-21)
ON	OFF	PI2(Parameters 00-22 & 00-23)
OFF	ON	PI3(Parameters 00-24 & 00-25)

When the Bit 1 of this parameter is set as 1, the pressure feedback is lower than the pressure stable region (please refer to the description of Parameter 00-26) so the flow control will be performed. When it enters the pressure stable region, the pressure control will be performed.

#### **01 Motor Parameters**

★ the parameter can be set during operation

#### 

Control mode VF FOCPG FOCPM Factory default: 5

0: V/F

1: Reserved

2: Reserved

Settings

3: FOCPG

4: Reserved

5: FOCPM

6: Reserved

This parameter determines the control mode of this AC motor.

0: V/F control, the user can design the required V/F ratio. It is used for induction motors.

1~2: Reserved

3: FOC vector control + Encoder. It is used for induction motors.

4: Reserved

5: FOC vector control + Encoder. It is used for synchronous motors.

6: Reserved

#### 🗸 🕃 🖁 - 🕃 🖁 Source of operation command

Control mode VF FOCPG FOCPM Factory default: 1

Settings 0: The operation command is controlled by the digital operation panel

1: The operation command is controlled by the external terminals. The STOP button on the keypad panel is disabled

2: The operation command is controlled by the communication interface. The STOP button on the keypad panel is disabled

60.00/50.00

For the operation command, press the PU button to allow the "PU" indicator to be lit. In this case, the RUN, JOG, and STOP button are enabled.

#### **∄ :- ∄ ?** Motor's maximum operation frequency

Control mode VF FOCPG FOCPM Factory default:

60.00/50.00

Settings 50.00 – 600.00Hz

Set the maximum operation frequency range of the motor. This setting is corresponding to the maximum flow for the system.

#### ☐ ! - ☐ ∃ Motor's rated frequency

Control mode VF FOCPG FOCPM Factory default:

Settings 0.00~600.00Hz

Typically, this setting is configured according to the rated voltage and frequency listed in the specifications on the motor's nameplate. If the motor is intended for 60Hz, set this value as 60Hz; if the motor is intended for 50Hz, set this value as 50Hz.

#### ## Hotor's rated voltage

Control mode VF FOCPG Factory default: 220.0/440.0

Settings 230V series: 0.1 – 255.0V

#### 460V series: 0.1 - 510.0V

Typically, this setting is configured according to the rated operation voltage shown on the motor's nameplate. If the motor is intended for 220V, set this value as 220.0V; if the motor is intended for 200V, set this value as 200.0V.

#### ★ # 1 - # 5 Acceleration time setting

Control mode VF FOCPG FOCPM Factory default: 0.00

Settings 0.00 - 600.00 seconds

#### ✓ ☐ I - ☐ ☐ ☐ Deceleration time setting

Control mode VF FOCPG FOCPM Factory default: 0.00

Settings 0.00 - 600.00 seconds

The acceleration time determines the time required for the Hybrid servo motor to accelerate from 0.0Hz to [the motor's maximum frequency] (01-02). The deceleration time determines the time required for the Hybrid servo motor to decelerate from [the motor's maximum frequency] (01-02) to 0.0Hz.

#### 

		Facto	ory de	efault: 0		
Settings	Control	mode	VF	FOCPG	FOCPM	
	0: No function		0	0		
	<ol> <li>Rolling test for induction motor(IM) (Rs, Rr, Lx, no-load current)</li> </ol>	Lm,	0	0		
	2: Static test for induction motor(IM)		0	0		
	3: Reserved					
	<ol> <li>Auto measure the angle between magnetic and PG origin</li> </ol>	pole			0	
	5: Rolling test for PM motor				0	


If the parameter is set as 1~2, it will perform the parameter automatic tuning for the Induction motor. In this case, press the [Run] button to perform the automatic measurement operation immediately. After the measurement is complete, the values are filled into Parameters 01-13~16 (no-load current, Rs, Rr, Lm, and Lx), respectively.

Induction motor AUTO-Tuning procedure:( Rolling test)

- All parameters of the Hybrid servo drive are set to factory settings and the motor is connected correctly.
- Users are strongly advised to disconnect the motor from any load before tuning. That is to say, the motor contains only the output shaft and connects to neither a belt nor a decelerator. Otherwise, it will be impossible to disconnect the motor from any loads. Static tuning is advised.
- 3. Set the rated voltage 01-04, rated frequency 01-03, rated current 01-08, rated power 01-09, rated speed 01-10, and number of poles 01-11 of the motor with correct values, respectively. For the acceleration/deceleration time, please set the correct values.
- 4. Set Parameter 01-07 as 1 and then press the RUN button on the keypad. The auto tuning process for the motor is carried out immediately. (Note: the motor starts running).
- 5. After the process is finished, check if the motor's parameters (parameters 01-13 ~ 16) have

been automatically entered with the measurement data.

6. Equivalent circuit of the motor





<sup>\*</sup> When the static tuning (parameters 01-07 = 2) is used, you must enter the no-load current of the motor. It is generally 20 to 50% of the rated current.

If the parameter is set as 5, it will perform the parameter automatic tuning for the synchronous motor. In this case, press the [Run] button to perform the automatic measurement operation immediately. After the measurement is complete, the values are filled into Parameters 01-22 (Rs), 01-23 & 24 (Ld & Lq), 01-25 (Back EMF of the synchronous motor), respectively.

Synchronous motor *AUTO-Tuning procedure*:(static measurement)

- All parameters of the Hybrid servo drive are set to factory settings and the motor is connected correctly.
- 2. Set the rated current 01-17, rated power 01-18, rated speed 01-19, and number of poles 01-20 of the motor with correct values, respectively. For the acceleration/deceleration time, please set the values according to the motor's capacity.
- Set Parameter 01-07 as 5 and then press the RUN button. The auto tuning process for the motor is carried out immediately. (Note: the motor starts running slightly).
- 4. After the process is finished, check if the motor's parameters (parameters 01-22 ~ 01-25) have been automatically entered with the measurement data.
- If the Parameter is set as 4, the automatic measurement of the angle between magnetic pole and the PG origin for the synchronous motor is performed. In this case, press the [Run] button to immediately perform automatic measurement. The measured data will be entered into Parameter 01 -27.

Angle between magnetic pole and the PG origin Auto-Tuning process for the synchronous motor:

- 1. After the measurement process for parameter value of 5 is performed completely or manually enter the Parameters 01-03, 01-17 and 01-25, respectively.
- 2. Before tuning, it is recommended to separate the motor and the load.
- 3. Set Parameter 01-07 as 4 and then press the RUN button on the keypad. The auto tuning process for the motor is carried out immediately. (Note: the motor starts running).
- 4. After the process is complete, please check if the values for the angle between magnetic poles and PG origin have been automatically entered in the Parameter 01-27.

# Rated current of the induction motor (A)

Control mode FOCPG Unit: Ampere

Factory default: #.##

Settings 40~120% of the rated driving current

To set this parameter, the user can set the rated motor current range shown on the motor's nameplate. The factory default is 90% of the rated current of the Hybrid servo drive.

For example: For the 7.5HP (5.5kW) motor, the rated current is 25, the factory settings: 22.5A.

The customers can set the parameter within the range 10 ~ 30A.

25\*40%=10 25\*120%=30

#### 

Control mode FOCPG Factory default: #.##

Settings 0 - 655.35kW

Set the motor's rated power. The factory default value is the power of the Hybrid servo drive.

#### Rated speed of the induction motor

Factory default:

Control mode FOCPG 1710 (60Hz 4-pole)

1410 (50Hz 4-pole)

Settings 0~65535

This parameter sets the rated speed of the motor. It is necessary to refer to the specifications shown on the motor's nameplate.

#### **! !-!!** Number of poles of the induction motor

Control mode FOCPG Factory default: 4

Settings 2~20

This parameter sets the number of motor number of poles (odd number is not allowed).

#### 

Control mode FOCPG Unit: Ampere

Factory default: 40

Settings 0~ Default value of Parameter 01-08

The factory default is 40% of the rated current of the Hybrid servo drive.

#### Stator resistance (Rs) of the induction motor

Control mode FOCPG Factory default: #.##

#### Rotor resistance (Rr) of the induction motor

Control mode FOCPG Factory default: #.##

Settings  $0\sim65.535\Omega$ 

#### # !- !5 Magnetizing inductance (Lm) of the induction motor

Control mode FOCPG Factory default: #.##

#### ## 15 Total leakage inductance (Lx) of the induction motor

Control mode FOCPG Factory default: #.##

Settings 0.0~6553.5mH

#### Rated current of the synchronous motor

Control mode FOCPM Factory default: 0.00

Settings 0~655.35 Amps

The user can set the rated current shown on the synchronous motor's nameplate.

#### Rated power of the synchronous motor

Control mode FOCPM Factory default: 0.00

Settings 0.00 – 655.35kW

This Parameter sets the rated power of the synchronous motor.

#### Rated speed of the synchronous motor

Control mode FOCPM Factory default: 0

Settings 0~65535

This parameter sets the rated speed of the synchronous motor. It is necessary to refer to the specifications shown on the motor's nameplate.

#### 

Control mode FOCPM Factory default: 6

Settings 2~20

This parameter sets the number of the synchronous motor's number of poles (odd number is not allowed).

#### ☐ ! - ? ! Inertia of the synchronous motor's rotor

Control mode FOCPM Factory default: 0.0

Settings 0.0~6553.5 \*10<sup>-4</sup> kg.m2

#### ☐ 1 - 2 ≥ Stator's phase resistance (Rs) oth the synchronous motor

Control mode FOCPM Factory default: 0

Settings  $0\sim65.535\Omega$ 

Enter the phase resistance of the synchronous motor.

# ☐ 1 - 2 3 stator's phase inductance(Ld) of the synchronous motor☐ 1 - 2 4 stator's phase inductance(Lq) of the synchronous motor

Control mode FOCPM Factory default: 0.00

Settings 0.0~655.35mH

Enter the synchronous motor's phase inductance. For surface type magnets (SPM), Ld = Lq; for built-in magnets (IPM), Ld ≠ Lq.

#### ☐ 1 - 25 Back EMF of the synchronous motor

Control mode FOCPM Factory default: 0

Settings 0~65535 V/krpm

Enter the back EMF of the synchronous motor.

#### 8 ! - 28 Encoder type selection

Control mode FOCPM Factory default: 3

Settings 0: ABZ

1: ABZ+HALL (only used for Delta's servo motors)

2: ABZ+HALL 3: Resolver

Look up table for Encoders & PG cards

Parameter Setting	Encoder Type	Applicable PG Card
01-26=0	A, B, Z	EMVJ-PG01U
01-26=1,2	A, B, Z+U, V, W	EMVJ-PG01U
01-26=3	Resolver	EMVJ-PG01/02R

#### ☐ :- 2 PG Offset angle of synchronous motor

Control mode FOCPM Factory default: 0.0

Settings  $0.0 \sim 360.0^{\circ}$ 

Offset angle of the PG origin for the synchronous motor.

#### **3 :-28** Number of poles of the resolver

Control mode FOCPM Factory default: 1

Settings 1~5

#### ## Encoder Pulse

Control mode FOCPG FOCPM Factory default: 1024

Settings 1~20000


This parameter can be set the encoder's number of pulses per revolution (PPR).

#### ☐ ! - 3☐ Encoder's input type setting


Control mode FOCPG FOCPM Factory default: 1

Settings 0: No function


1: Phase A leads in a forward run command and phase B leads in a reverse run command.




2: Phase B leads in a forward run command and phase A leads in a reverse run command.




3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction).



4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction).



5: Single-phase input



Enter the correct setting for the pulse type is helpful in controlling the stability.

#### : : - 3 : System control

Control mode FOCPG FOCPM Factory default: 1

Settings 0: No function

1: ASR automatic tuning

2: Estimation of inertia

If the setting value is 1: The speed control gain is determined by Parameters 00-10

If the setting value is 2: The system inertia is estimated. Please refer to descriptions in Chapter 3

#### Unity value of the system inertia

Control mode FOCPG FOCPM Factory default: 400

Settings  $1\sim65535$  (256 = 1 per unit)

#### ☐ ! - ∃ ∃ Carrier frequency

Control mode FOCPG FOCPM Factory default: 5

Settings 5 kHz; 10kHz

- When this parameter is configured, please re-start the Hybrid servo drive.
- The carrier frequency of the PWM output has a significant influence on the electromagnetic noise of the motor. The heat dissipation of the Hybrid servo drive and the interference from the environment may also affect the noise. Therefore, if the ambient noise is greater than the motor noise, reducing the carrier frequency of the drive may have the benefits of reducing a temperature rise; if the carrier frequency is high, even if a quiet operation is obtained, the overall wiring and interference control should be taken into consideration.

#### ★ 日 : - 3 Reserved

#### # 1-35 Motor ID

Control mode FOCPG FOCPM Factory default: 0

Settings 0 : No function

16: Delta's Hybrid servo motor ECMA-ER181BP3 (11kW220V)

17: Delta's Hybrid servo motor ECMA-KR181BP3 (11kW380V)

18: Delta's Hybrid servo motor ECMA-ER221FPS (15kW220V)

19: Delta's Hybrid servo motor ECMA-KP221FPS (15kW380V)

21: Delta's Hybrid servo motor ECMA-KR222APS (20kW380V)

#### **31-35** Change the rotation direction

Control mode FOCPG FOCPM Factory default: 0

Settings

- 0: When the driver runs forward, the motor rotates counterclockwise. When the driver runs reverse, the motor rotates clockwise.
- 1: When the driver runs forward, the motor rotates clockwise. When the driver runs reverse, the motor rotates counterclockwise.
- This parameter can be modified only when the machine is shut down. For an induction motor after the parameters are configured completely, it will change the running direction. For a synchronous motor, it is necessary to perform the magnetic pole detection and re-start the drive.

#### **0-2 Parameters for Protection**

✓ the parameter can be set during operation

# 

Control mode VF FOCPG FOCPM

Factory default: 380.0/760.0

Settings 230V series: 350.0~450.0Vdc

460V series: 700.0~900.0Vdc

Sets the reference point of software brake. The reference value is the DC bus voltage.

82-81	Present fault record
88-88	Second most recent fault record
02-03	Third most recent fault record
02-04	Fourth most recent fault record
88-88	Fifth most recent fault record
88-88	Sixth most recent fault record

Settings	Control mode	VF	FOCPG	FOCPM
0: No error record		0	0	0
1: Over-current during acceleration (ocA)		0	0	0
2: Over-current during deceleration (ocd)		0	0	0
3: Over-current during constant speed (ocn)		0	0	0
4: Ground fault (GFF)		0	0	0
5: IGBT short-circuit (occ)		0	0	0
6: Over-current at stop (ocS)		0	0	0
7: Over-voltage during acceleration (ovA)		0	0	0
8: Over-voltage during deceleration (ovd)		0	0	0
9: Over-voltage during constant speed (ovn)		0	0	0
10: Over-voltage at stop (ovS)		0	0	0
11: Low-voltage during acceleration (LvA)		0	0	0
12: Low-voltage during deceleration (Lvd)		0	0	0
13: Low-voltage during constant speed (Lvn)		0	O	0
14: Low-voltage at stop (LvS)		0	O	0
15: Phase loss protection (PHL)		0	O	0
16: IGBT over-heat (oH1)		0	O	0
17: Heat sink over-heat for 40HP and above (o	H2)	0	O	0
18: TH1 open: IGBT over-heat protection circuit	it error (tH1o)	0	O	0
<ol> <li>TH2 open: heat sink over-heat protectio (tH2o)</li> </ol>	n circuit error	0	0	0
20: Fan error signal output (Fan)		0	0	0
21: Hybrid servo drive overload (oL)		0	0	0
22: Motor 1 overload (EoL1)		0	0	0
23: Reserved				
24: Motor over-heat, detect by PTC (oH3)		0	0	0
25: Reserved				

26: Over-torque 1 (ot1)	0	0	0
27: Over-torque 2 (ot2)	0	0	0
28: Reserved			
29: Reserved			
30: Memory write error (cF1)	0	0	0
31: Memory read error (cF2)	0	0	0
32: Isum current detection error (cd0)	0	0	0
33: U-phase current detection error (cd1)	0	0	0
34: V-phase current detection error (cd2)	0	0	0
35: W-phase current detection error (cd3)	0	0	0
36: Clamp current detection error (Hd0)	0	0	0
37: Over-current detection error (Hd1)	0	0	0
38: Over-voltage current detection error (Hd2)	0	0	0
39: Ground current detection error (Hd3)	0	0	0
40: Auto tuning error (AuE)			0
41: Reserved	0	0	0
42: PG feedback error (PGF1)		0	0
43: PG feedback loss (PGF2)		0	0
44: PG feedback stall (PGF3)		0	0
45: PG feedback slip (PGF4)		0	0
46: Reserved	0	0	0
47: Reserved	0	0	0
48: Reserved			
49: External fault input (EF)	0	0	0
50: Emergency stop (EF1)	0	0	0
51: Reserved			
52: Password error (PcodE)	0	0	0
53: Reserved			
54: Communication error (cE1)	0	0	0
55: Communication error (cE2)	0	0	0
56: Communication error (cE3)	0	0	0
57: Communication error (cE4)	0	0	0
58: Communication time out (cE10)	0	0	0
59: PU time out (cP10)	0	0	0
60: Braking transistor error (bF)	0	0	0
61~63: Reserved	0	0	0
64: Safety relay Error (SRY)	0	0	0
65: PG card information error (PGF5)			0
66: Over pressure (ovP)	0	0	0
67: Pressure feedback fault (PfbF)	0	0	0

As a fault occurs and the machine is forced shutting down, the event will be recorded. During shutting down, the LvS is not recorded.


## ★ B 2 - B 7 Low voltage level

Control mode VF FOCPG FOCPM Factory default: 180/360

Settings 230V Series: 160 – 220V

460V Series: 320 - 440V

This parameter is used to set the LV discrimination level.



#### 

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: Warn and keep operation

1: Warn and ramp to stop2: Warn and coast to stop

Parameter 02-08 is used to define the operation mode of the drive after the PTC is activated.

#### ✓ ☐ - ☐ PTC level

Control mode VF FOCPG FOCPM Factory default: 50.0

Settings 0.0~150.0% 0.0~150.0°C

This parameter defines the maximum value of the analog input for 100% of the activation level of the PTC.

#### 

Control mode VF FOCPG FOCPM Factory default: 0.20

Settings 0.00 - 10.00 seconds

#### 

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: Not assigned

1: KTY84

When this parameter is set as 1, the unit for Parameters 02-09 and 02-12 will be changed from % to °C.

#### ★ ## Motor fan activation level

Control mode VF FOCPG FOCPM Factory default: 50.0

Settings 0.0~100.0%

0.0~150.0℃

When the Parameters 03-05 to 03-07 for the multi-function output terminal are set to 45, the motor fan will start or stop according to this parameter setting.

#### ★ # # Electronic thermal relay selection 1

Control mode VF FOCPG FOCPM Factory default: 2

Settings 0: Inverter motor

1: Standard motor

2: Disable

#### ★ ## Electronic thermal characteristic for motor

Control mode VF FOCPG FOCPM Factory default: 60.0

Settings 30.0 - 600.0 seconds

To prevent self-cooled motor from over heating at low speed operation, the user can set the electronic thermal relay to limit the allowed output power of the Hybrid servo drive.

#### #2 - 15 Output frequency at malfunction

Control mode Factory default: Read

only

Settings 0.00 - 655.35Hz

#### ## Ourput voltage at malfunction

Control mode Factory default: Read

VF FOCPG FOCPM

only

Settings 0.0 - 6553.5V

#### **BC-11** DC side voltage at malfunction

Control mode Factory default: Read

only

Settings 0.0 - 6553.5V

#### 82 - 18 Ourput current at malfunction

Control mode VF FOCPG FOCPM Factory default: Read

only

Settings 0.00~655.35Amp

#### ## IGBT temperature at malfunction

Control mode Factory default: Read

FOCPG FOCPM only

Settings 0.0~6553.5℃

# **03 Digital/Analog Input/Output Parameters** $\varkappa$ the parameter can be set during operation

**R3-8** Multi-function input command 4 (MI4) Multi-function input command 5 (MI5) **FOCPG FOCPM** Factory default: 0 Control mode Settings 0: No function 44: Injection signal input 45: Confluence/Diversion signal input 46: Reserved 47: Multi-level pressure PI command 1 48: Multi-level pressure PI command 2 When the value of this parameter is set as 44, the pressure feedback is lower than the pressure stable region (please refer to the description of Parameter 00-26) so the flow control will be performed. When it enters the pressure stable region, the pressure control will be performed. If the setting value is 45, the confluence (OFF)/diversion (ON) function will be performed. For detailed operation, please refer to Chapter 2 for wiring and Chapter 3 for tuning. Please refer to the description Parameters 00-36 if the setting value is 47 and 48, Digital input response time Control mode **FOCPG FOCPM** Factory default: 0.005 0.001~30.000 sec Settings This parameter is used to delay and confirm the signal on the digital input terminal. HE-HY Digital input operation direction **FOCPG FOCPM** Control mode Factory default: 0 0~65535 Settings This parameter defines the activation level of the input signal. Bit 0 for the SON terminal, bit 2 for the EMG terminal, bit 3 for the RES terminal, bits 4~6 correspond to MI3~MI5, respectively. Multi-function output 1 (Relay 1) Control mode FOCPG FOCPM Factory default: 11 Multi-function Output 2 (MOI) FOCPG FOCPM Control mode Factory default: 0 **/ HEI-H** Multi-function Output 3 (MO2) FOCPG FOCPM Control mode Factory default: 0 Settings 0: No function 1: Operation indication 9: Hybrid servo drive is ready 11: Error indication 44: Displacement switch signal 45: Motor fan control signal

×	03-08	Multi-f	unction	output directio	n	
	Control mode	VF	FOCPG	FOCPM	Factory	y default: 0
		Settings	0~6	5535		
	This pa	rameter i	s used for	bit-wise setting. If t	he corresponding bit is 1, the mult	i-function output is
	set as r	everse di	irection.			
N	03-09	Low-pa	ass filteri	ng time of keypa	d display	
	Control mode	-	FOCPG	FOCPM	•	y default: 0.010
		Settings	0.0	01~65.535 seconds	•	
	This pa	arameter	can be se	t to reduce the fluc	uation of the readings on the keya	apd.
	00_ 10	Mavim	um out	out voltage for	oressure feedback	
	Control mode		FOCPG			default: 10.0
	Common mode	Settings		~10.0 V	1 dotory c	Totalii. 10.0
	83-11	Minim	um outp	ut voltage for p	ressure feedback	
	Control mode		FOCPG	FOCPM		y default: 0.0
		Settings	0.0	~1.0V		
	This pa	rameter o	defines the	e pressure feedbacl	output voltage type.	
	If the pr	ressure fe	eedback h	as a bias, can adju	st this parameter to eliminate the b	oias.
	03-12	Roser	hav			
	03 16	1103CI	vcu			
	03-13	Conflu	ence Ma	aster/Slave Sele	ection	
	Control mode		FOCPG	FOCPM		y default: 0
		Settings	0: 1	No function		
			1: 1	Master 1		
			2: 3	Slave/Master 2		
			3: 8	Slave/Master 3		
	In a sta	nd-alone	system, t	his parameter is set	as 0	
	In a cor	nfluence	system, th	e parameter is set a	as 1 for the Master and 2 for the S	lave
	With m	ulti-functi	on input te	erminal function 45,	the confluence/diversion can be of	onfigured. For
		•	•	•	or wiring and Chapter 3 for tuning	
					3 is that the Master 3 can be confi	
			s during c	onfluence, however	, the Master 2 can be configured t	or stand-alone
	operation	on.				
	83-14	Slave's	s propo	tion of the Mas	ter's flow	
	Control mode	VF	FOCPG	FOCPM	Factory	y default: 100.0
		Settings	0.0	~65535.5 %		
	This pa	rameter	setting is r	equired only for the	Master but not needed for the Sla	ave.
	∭ In a cor	nfluence	evetom th	is narameter value	defines the Slave's portion of the	Master's flow

Example: Slave is 60L/min and Master is 40L/min, so the setting is 60/40 \* 100% = 150% For confluence of more than 2 pump, the values for the slaves must be the same. For example, if the total flow for a three-pump system is 200L/min, where the Master is 40L/min, then the two Slaves should be 80L/min. The setting of Parameter 03-14 should be 160/40 = 400%

	Couloc (		luency command	
Control mode	e VF F	OCPG	FOCPM	Factory default: 0
	Settings	0: Γ	Digital Operation Panel	
		1: F	RS485 Communication	
		2~5	5: Reserved	
This pa	rameter is ι	used for	EMVJ-MF01.For detailed opera	ation, please refer to Chapter 3 for
tuning.				
In a cor	ıfluence sys	stem, if	the Slave's frequency command	l is given through the RS485
commu	nication, the	e setting	g value should be 1.	
03-18	Limit for	the S	slave reverse depressuriza	ation torque
Control mode		OCPG	FOCPM	Factory default: 20
	Settings	0~!	500%	. detery deradic 20
☐ Set the			e Slave's reverse operation.	
רו בח	Clava'a		tion lovel	
	Slave's a			Factory default: 50
Control mode		OCPG	FOCPM	Factory default: 50
<b>── T</b> L:	Settings		100%	and an analysis of the second
· ·		_	equired only for the Master but r	
-	rameter dei the Master.	termine	s the activation level for the Slav	e. A 100% value corresponds to the fo
now or	lile Master.			
81 - 68	Commu	nicatio	on error treatment	
Control mode	e VF F	OCPG	FOCPM	Factory default: 0
	Settings	0: V	Warn and keep operation	
		1: V	Warn and ramp to stop	
		2: \	Warn and coast to stop	
		3: 1	No action and no display	
	-			
☐ This pa	 ırameter is ı	used to	set the handling status of the dri	ve when a communication timeout err
•	arameter is one		· ·	ve when a communication timeout err
•	as disconne	ction) o	ccurs.	ve when a communication timeout err
•	as disconne Time-ou	ction) o	ccurs.	ve when a communication timeout err  Factory default: 0.0

★ ☐ 3 - 2 ☐ Start-up display selection

4. Description of Parameters

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: F (frequency command)

1: H (actual frequency)

2: Multi-function display (user-defined 00-04)

3: A (Output current)

This parameter is used to set the contents of the start-up screen. The content of the user-defined option is displayed in accordance with the setting value of Parameter 00-04.

#### ✓ ☐ 3 - 2 ↑ Slave reverse operation for depressurization

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: Disabled 1: Enabled

- This parameter setting is required only for the Slave but not needed for the Master.
- When the parameter is set as 1, it is necessary to make sure that the outlet end of the Slave is not installed with any one-way valve and the parameter 03-16 is set as 500.

# 5. Fault Codes and Descriptions

- 5-1 Error Messages
- 5-2 Over Current OC
- 5-3 Ground Fault GFF
- 5-4 Over Voltage OV
- 5-5 Low Voltage Lv
- 5-6 Over Heat OH1
- 5-7 Overload OL
- 5-8 Phase Loss PHL
- 5-9 Electromagnetic/Induction Noise
- 5-10 Environmental Condition


The Hybrid servo drive has warning messages and protection functions such as over-voltage, low-voltage, over-current, etc. Once a fault occurs, the protection function is activated, the Hybrid servo drive stops output, and the motor coast to stop. Please look up the cause for the fault and perform the countermeasure according to the error message of the Hybrid servo drive. The error records are stored in the internal memory of the Hybrid servo drive (last six error messages can be recorded) and can be read out through the keypad or through the communication port.



- ☑ After a fault occurs, the RESET button will be effective only 5 seconds after the fault condition is released.
- oxdots For Hybrid servo drives of power rating  $\leq$  22kW, it is necessary to wait for 5 minutes (10 minutes for  $\geq$  30kW) after the power is shut down to confirm that the indicator light is off and the measured DC voltage across the terminals  $\oplus$  and  $\ominus$  is below DC 25V before opening the cover for inspection.

# 5-1 Error Messages

# 5-1-1 Light indication



- 1 Indicator of PG card power
- (2) Indicator of Encoder feedback
- 3 Warning indicator

When the sin or cos phase voltage is lower than required values in the rotational transformer, the warning indicator will be on. Please check if the encoder wire is connected correctly. If it happens in operation, please check for any interference.

**Power indicator** 

Powerindicator

# 5-1-2 Error Messages Displayed on KPVJ-LE01 Digital Keypad Panel

Displayed Code	Description of Failure	Solutions
	Over current during acceleration;	
ū	the output current exceeds three	
och	times the rated current of the Hybrid	
	servo drive.	Check the connection from U-V-W to the motor for any
	Over current during deceleration;	improper insulation.
,	the output current exceeds three	Check if the motor is jammed.
ocd	times the rated current of the Hybrid	Replace with an AC motor drive with a larger output
	servo drive.	capacity.
	Over current during constant speed	
	operation; the output current	
000	exceeds three times the rated	
	current of the Hybrid servo drive.	
	Over-current when the machine	
065	stops. Malfunction of the current	Return to factory for repair.
	detection circuit	
	The Hybrid servo drive detects short	Return to factory for repair.
occ	circuit between the IGBT module's	
	upper and lower bridges.	
	During acceleration, the Hybrid	230V: DC 450V
ouX	servo drive detects over-voltage at	460V: DC 900V
	the internal DC side.	Check if the input voltage is within the Hybrid servo
	During deceleration, the Hybrid	drive's rated voltage range; and monitor if there is any
വെർ	servo drive detects over-voltage at	voltage surge.
	the internal DC side.	For Hybrid servo drives below 22kW, the Parameter
		02-00 can be adjusted for the activation level of the
	During the constant speed	braking transistor
aa	operation, the Hybrid servo drive	For Hybrid servo drives above 22kW, adjust the brake
000	detects over-voltage at the internal	activation level of the braking unit
	DC side.	(For detailed description, please refer to the operation
		manual of the braking unit)
	Over-voltage when the machine	Check if the input voltage is within the Hybrid servo
כטס	stops. Malfunction of the voltage	drive's rated voltage range; and monitor if there is any
	detection circuit	voltage surge.
	During acceleration, the Hybrid	Check if the voltage of the input power supply is
! 8	servo drive's DC side voltage is	normal.
	lower than the setting value of	Check if there is any sudden heavy load.
	Parameter 02-07.	Adjust Parameter 02-07 for the low-voltage level

Displayed Code	Description of Failure	Solutions
	During deceleration, the Hybrid	
	servo drive's DC side voltage is	
Lud	lower than the setting value of	
	Parameter 02-07.	
	During constant speed operation,	
	the Hybrid servo drive's DC side	
Lun	voltage is lower than the setting	
	value of Parameter 02-07.	
	When the machine stops, the Hybrid	
	servo drive's DC side voltage is	
LuS	lower than the setting value of	
	Parameter 02-07.	
		Check if the single-phase input is used for the
ОШ	Dhana lana anatantian	three-phase model or there is any phase loss.
rni	Phase loss protection	Check if it is a model with capacity higher than 40HP.
		If so, please check the AC-side fuse for burning.
	Ground protection is activated.	
	When the Hybrid servo drive detects	Charle the connection to the motor for short circuit or
	the output end is grounded and the	Check the connection to the motor for short circuit or
$\Gamma$	grounding current is larger than 50%	ground fault.
UFF	of the Hybrid servo drive's rated	Make sure if the IGBT power module is damaged.
	current. Note: Such a protection is	Check the connection at the output side is improperly
	used for protecting the Hybrid servo	insulated.
	drive not for human body.	
	The Hybrid servo drive detects	
	overheat of the IGBT with a	Check if the ambient temperature is too high.
11.1	temperature higher than the	Check if the heat sink for any external object. Check
on i	protection level	the fan is running.
	7.5 – 15HP: 90℃	Check if the Hybrid servo drive has sufficient space.
	20 – 100HP: 100℃	
	The Hybrid servo drive detects	Check if the ambient temperature is too high.
117	overheat of the heat sink with a	Check if the heat sink for any external object. Check
oHZ	temperature higher than the	the fan is running.
	protection level (90°ℂ)	Check if the Hybrid servo drive has sufficient space.
	The Hybrid servo drive detects the	Check if the motor is jammed.
117	motor internal overheat which is	Check if the ambient temperature is too high.
oKj	higher than the protection level	Increase the capacity of the motor
	(02-09 PTC level)	
	Fan fails	Check if the fan is blocked.


The output current is higher than the withstand current of the Hybrid servo drive.  E o L I Motor overload Change the product condition  F U S E DC side fuse (FUSE) burns for models of 30HP and below.  C F I Memory write error.  C F C Memory read error.  Error of the sum of the three-phase output current is detected.  Error V-phase current is detected.  Error V-phase current is detected.  Error V-phase current is detected.  Error W-phase current is detected.  After restart the power supply, if the error still exists, return to factory for repair.  After clearing the cause of the error, press the "RESET" button.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  Error W-phase circuit error  C G C C C C C C C C C C C C C C C C C	Displayed Code	Description of Failure	Solutions
withstand current of the Hybrid servo drive servo drive.  **E o ! ** Motor overload**  **P S E			
Servo drive.    Change the product condition	o!	withstand current of the Hybrid	
Check the fuse of the transistor module is burning. Check the load side for any short circuit Press the RESET button to reset the parameters to factory default settings.  If this method does not work, return to factory for repair.  Error U-phase current is detected.  Error W-phase current is detected.  Error W-phase current is detected.  Error W-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  EFF I Check the fuse of the transistor module is burning. Check the load side for any short circuit error Return to reset the parameters to factory default settings.  If this method does not work, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  EFF I OH1 hardware circuit error Return to factory for repair.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.		servo drive.	increase the output capacity of the Hybrid servo drive.
models of 30HP and below.  Check the load side for any short circuit  Press the RESET button to reset the parameters to factory default settings.  If this method does not work, return to factory for repair.  Error of the sum of the three-phase output current is detected.  Error U-phase current is detected.  Error W-phase current is detected.  Codd Error W-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After restart the power supply, if the error still exists, please return to factory for repair.  After restart the power supply, if the error still exists, please return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	EoL !	Motor overload	Change the product condition
Memory write error.  Error of the sum of the three-phase output current is detected.  Error V-phase current is detected.  Error W-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive detects errors from the braking transistor.  The Hybrid servo drive detects errors from the braking transistor.  What is the RESET button to reset the parameters to factory default settings.  If this method does not work, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  Children the tack the parameters to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	c $cc$	DC side fuse (FUSE) burns for	Check if the fuse of the transistor module is burning.
Memory write error.  Memory read error.  Error of the sum of the three-phase output current is detected.  Error U-phase current is detected.  Error V-phase current is detected.  Error W-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  The Hybrid servo drive detects errors from the braking transistor.  OH1 hardware circuit error  OH2 hardware circuit error  oc protection hardware circuit error  ov protection hardware circuit error  Over protection hardware circuit error  Over protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	ruje	models of 30HP and below.	Check the load side for any short circuit
repair.  After restart the power supply, if the error still exists, return to factory for repair.  return to factory for repair.  After clearing the cause of the error, press the "RESET" button.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	cF!	Memory write error.	
color but current is detected.  Error U-phase current is detected.  Error V-phase current is detected.  Error W-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  CH 1 hardware circuit error  CH 2 hardware circuit error  CC protection hardware circuit error  OV protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	c F 2	Memory read error.	
Error U-phase current is detected.  Error V-phase current is detected.  Error W-phase current is detected.  Error W-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  The Hybrid servo drive detects errors from the braking transistor.  The Hybrid servo drive detects errors from the braking transistor.  CH1 hardware circuit error  CH2 hardware circuit error  CC protection hardware circuit error  ONE protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.		Error of the sum of the three-phase	
After restart the power supply, if the error still exists, return to factory for repair.  Error V-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  After the power supply, if the error still exists, return to factory for repair.  After press the RESET button and press the Return to factory for repair.  After the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	COU	output current is detected	
Error V-phase current is detected.  When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  The Hybrid servo drive detects errors from the braking transistor.  OH1 hardware circuit error  OH2 hardware circuit error  oc protection hardware circuit error  ov protection hardware circuit error  GFF protection hardware circuit  Error V-phase current is detected.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  Return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	cdi	Error U-phase current is detected.	After restart the power supply, if the error still exists,
When the external EF terminals close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  CH1 hardware circuit error  Return to factory for repair.  CC protection hardware circuit error  oc protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	cd2	Error V-phase current is detected.	return to factory for repair.
After clearing the cause of the error, press the "RESET" button.  When the external EMG terminals close, the Hybrid servo drive stops output.  The Hybrid servo drive detects errors from the braking transistor.  OH1 hardware circuit error  OH2 hardware circuit error  oc protection hardware circuit error  ov protection hardware circuit error  OFF protection hardware ci	cd3	Error W-phase current is detected.	
close, the Hybrid servo drive stops output.  When the external EMG terminals close, the Hybrid servo drive stops output.  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  OH1 hardware circuit error  CH2 hardware circuit error  CC protection hardware circuit error  oc protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.		When the external EF terminals	After clearing the cause of the error press the
When the external EMG terminals close, the Hybrid servo drive stops output.  The Hybrid servo drive detects errors from the braking transistor.  OH1 hardware circuit error  OH2 hardware circuit error  cc protection hardware circuit error  ov protection hardware circuit error  OFF protection hardware circuit error  OFF protection hardware circuit  OFF protection hardware circuit  OFF protection hardware circuit  After clearing the cause of the error, press the "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  Return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	<b>&amp; &gt;</b>		
After clearing the cause of the error, press the "RESET" button.  The Hybrid servo drive detects errors from the braking transistor.  OH1 hardware circuit error  OH2 hardware circuit error  Cc protection hardware circuit error  Oc protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.			
output.  The Hybrid servo drive detects errors from the braking transistor.  OH1 hardware circuit error  OH2 hardware circuit error  oc protection hardware circuit error  ov protection hardware circuit error  OFF protection hardware circuit  OFF protection hardware circuit  "RESET" button.  After press the RESET button, if the message bF still exists, please return to factory for repair.  Return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.	$\Gamma\Gamma$		After clearing the cause of the error, press the
errors from the braking transistor.  Exico OH1 hardware circuit error Return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.  After restart the power supply, if the error still exists, return to factory for repair.			"RESET" button.
OH1 hardware circuit error  Return to factory for repair.  CH2 hardware circuit error  CC protection hardware circuit error  OC protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  GFF protection hardware circuit	<u> </u>	The Hybrid servo drive detects	After press the RESET button, if the message bF still
OH2 hardware circuit error  Cc protection hardware circuit error  Oc protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  OFF protection hardware circuit	07	errors from the braking transistor.	exists, please return to factory for repair.
cc protection hardware circuit error  oc protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  GFF protection hardware circuit	<b>EX 10</b>	OH1 hardware circuit error	Return to factory for repair.
oc protection hardware circuit error  After restart the power supply, if the error still exists, return to factory for repair.  GFF protection hardware circuit  GFF protection hardware circuit	£#20	OH2 hardware circuit error	Return to factory for repair.
After restart the power supply, if the error still exists, return to factory for repair.  GFF protection hardware circuit  GFF protection hardware circuit	Ras	cc protection hardware circuit error	
ov protection hardware circuit error  GFF protection hardware circuit	Hd:	oc protection hardware circuit error	After restart the power supply, if the error still exists,
	888	ov protection hardware circuit error	return to factory for repair.
error	417	GFF protection hardware circuit	
	000	error	

Displayed Code	Description of Failure	Solutions
P5F2	PG feedback loss	Check the PG feedback connection.
PGF3	PG feedback stall	Check the PG feedback connection. Check if the PI gain and the acceleration/deceleration
PGFY	PG feedback slip error	settings are proper.  Return to factory for repair.
PSFS	PG Card information error	Check if the setting value of the Parameter 01-26 matches the installed PG Card. For details, please refer to the description of Parameter 01-26. If there is no error found, please return it to factory for repair.
5-3	Safe circuit card/control board jumper JP18 has improper installation or faulty activation	Check if the safety circuit card is installed correctly in the control board and the output action for any fault.  Check the control board jumper JP18 for incorrect position.
oup	Over pressure	Check if the pressure sensor for any fault.  Adjust the pressure PI control parameters  00-20~00-37
PFbF	Pressure feedback loss	Check if the wiring of the pressure sensor is correct.  Check if the signal of the pressure sensor is lower than 1V.


#### **Alarm Reset**

After the cause of the alarm is cleared from the tripped state, press the RESET button on the keypad (as shown in the figure), set the external terminal as a "Error Reset Command" and then connect the terminal, or send error reset command through the communication port to release the tripped state of the machine. Before rest any error alarm, the operation signal should be open (OFF) so as to prevent the sudden running of the machine immediately after the recovery from error signal and causing damage or injury.







## 5-2 Over Current oc




# 5-3 Ground Fault Factor GFF




# 5-4 Over Voltage ov




# 5-5 Low Voltage Lv




# 5-6 Over Heating oH1



# 5-7 Over Load oL



# 5-8 Phase Loss PHL



# 5-9 Electromagnetic/Induction Noise

There are many noises surround the Hybrid servo drive and invade it by radiation or power circuit. It may cause the misoperation of control circuit and even damage the Hybrid servo drive. Of course, that is a solution to increase the noise tolerance of the Hybrid servo drive. But it is not the best one due to the limit. Therefore, solve it from the outside as following will be the best.

- Add surge killer on the relay or contact to suppress switching surge between ON/OFF.
- 2. Shorten the wiring length of the control circuit or serial circuit and separate from the main circuit wiring.
- 3. Comply with the wiring regulation for those shielded wire and use isolation amplifier for long wire.
- The grounding terminal should comply with the local regulation and ground independently, i.e. not to have common ground with electric welding machine and power equipment.
- 5. Connect a noise filter at the input terminal of the Hybrid servo drive to prevent noise from power circuit.

In a word, three-level solutions for electromagnetic noise are "no product", "no spread" and "no receive".

#### 5-10 Environmental Condition

Since Hybrid servo drive is an electronic device, you should comply with the environmental condition stated in the appendix A. Following are the remedial measures for necessary.

- 6. To prevent vibration, anti-vibration spacer is the last choice. The vibration tolerance must be within the specification. The vibration effect is equal to the mechanical stress and it cannot occur frequently, continuously or repeatedly to prevent damaging Hybrid servo drive.
- Store in a clean and dry location free from corrosive fumes/dust to prevent rustiness, poor contact. It also may cause short by low insulation in a humid location. The solution is to use both paint and dust-proof. For particular occasion, use the enclosure with whole-seal structure.
- 8. The surrounding temperature should be within the specification. Too high or low temperature will affect the lifetime and reliability. For semiconductor components, damage will occur once any specification is out of range. Therefore, it is necessary to clean and periodical check for the air cleaner and cooling fan besides having cooler and sunshade. In additional, the microcomputer may not work in extreme low temperature and needs to have heater.
  - 1. Store within a relative humidity range of 0% to 90% and non-condensing environment. Do not turn off the air conditioner and have exsiccator for it.

# Suggestions and Error Corrections for Hybrid Servo Drives

- 6-1 Maintenance and Inspections
- 6-2 Greasy Dirt Problem
- 6-3 Fiber Dust Problem
- 6-4 Erosion Problem
- 6-5 Industrial Dust Problem
- 6-6 Wiring and Installation Problem
- 6-7 Multi-function Input/Output Terminals Problem

The Hybrid servo drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the Hybrid servo drive digital keypad display. The six most recent faults can be read from the digital keypad or communication.

The Hybrid servo drive is made up by numerous components, such as electronic components, including IC, resistor, capacity, transistor, and cooling fan, relay, etc. These components can't be used permanently. They have limited-life even under normal operation. Preventive maintenance is required to operate this Hybrid servo drive in its optimal condition, and to ensure a long life.

Check your Hybrid servo drive regularly to ensure there are no abnormalities during operation and follows the precautions:



- ☑ Wait 5 seconds after a fault has been cleared before performing reset via keypad of input terminal.
- oxdots When the power is off after 5 minutes for  $\leq$  22kW models and 10 minutes for  $\geq$  30kW models, please confirm that the capacitors have fully discharged by measuring the voltage between + and -. The voltage between + and should be less than 25VDC.
- ☑ Only qualified personnel can install, wire and maintain drives. Please take off any metal objects, such as watches and rings, before operation. And only insulated tools are allowed.
- ☑ Never reassemble internal components or wiring.
- ☑ Make sure that installation environment comply with regulations without abnormal noise, vibration and smell.

# 6-1 Maintenance and Inspections

Before the check-up, always turn off the AC input power and remove the cover. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between DC+ and DC-. The voltage between DC+ and DC-should be less than 25VDC.

#### **Ambient environment**

		Ма	aintenance		
Check Items	Methods and Criterion		Period		
		Daily	Half Year	One Year	
Check the ambient temperature, humidity,	Visual inspection and				
vibration and see if there are any dust, gas,	measurement with equipment	$\circ$			
oil or water drops	with standard specification				
If there are any dangerous objects	Visual inspection	0			

#### Voltage

Check Items	Methods and Criterion		laintenance Period	
		Daily	Half Year	One Year
Check if the voltage of main circuit and	Measure with multimeter with	0		
control circuit is correct	standard specification			

#### **Digital Keypad Display**

Check Items	Methods and Criterion		aintenance Period	
		Daily	Half Year	One Year
Is the display clear for reading	Visual inspection	0		
Any missing characters	Visual inspection	0		

#### **Mechanical parts**

		Ma	intenar	псе
Check Items	Methods and Criterion	Period		
		Daily	Half Year	One Year
If there is any abnormal sound or vibration	Visual and aural inspection		$\circ$	
If there are any loose screws	Tighten the screws		0	
If any part is deformed or damaged	Visual inspection		0	
If there is any color change by overheating	Visual inspection		0	
If there is any dust or dirt	Visual inspection		0	

#### Main circuit

			aintenance		
Check Items	Methods and Criterion	Perio		od	
		Daily	Half Year	One Year	
If there are any loose or missing screws	Tighten or replace the screw	0			
If machine or insulator is deformed, cracked,	Visual inspection				
damaged or with color change due to	NOTE: Please ignore the				
overheating or ageing	color change of copper				
overneating or ageing	plate				
If there is any dust or dirt	Visual inspection		0		

#### Terminals and wiring of main circuit

		Ма	laintenance		
Check Items	Methods and Criterion	Period			
		Daily	Half Year	One Year	
If the terminal or the plate is color change or deformation due to overheat	Visual inspection		0		
If the insulator of wiring is damaged or color change	Visual inspection		0		
If there is any damage	Visual inspection	0			

#### DC capacity of main circuit

		Ма	intenar	ntenance		
Check Items	Methods and Criterion	Period				
		Daily	Half Year	One Year		
If there is any leak of liquid, color change, crack or deformation	Visual inspection	0				
If the safety valve is not removed? If valve is inflated?	Visual inspection	0				
Measure static capacity when required		0				

#### Resistor of main circuit

		Ма	aintenance		
Check Items	Methods and Criterion		Period		
		Daily	Half Year	One Year	
If there is any peculiar smell or insulator	Visual inspection, smell	$\circ$			
cracks due to overheat					
If there is any disconnection	Visual inspection	$\circ$			
If connection is demaged?	Measure with multimeter with	0			
If connection is damaged?	standard specification				

#### Transformer and reactor of main circuit

Check Items	Methods and Criterion		aintenance Period	
		Daily	Half Year	One Year
If there is any abnormal vibration or peculiar	Visual, aural inspection and			
smell	smell			

#### Magnetic contactor and relay of main circuit

Check Items	Methods and Criterion		aintenance Period	
		Daily	Half Year	One Year
If there are any loose screws	Visual and aural inspection	0		
If the contact works correctly	Visual inspection	0		

#### Printed circuit board and connector of main circuit

		Maintenance			
Check Items	Methods and Criterion	Period			
		Daily	Half Year	One Year	
	Tighten the screws and		$\circ$		
If there are any loose screws and connectors	press the connectors firmly				
	in place.				
If there is any peculiar smell and color change	Visual and smell inspection		0		
If there is any crack, damage, deformation or	Visual inspection		0		
corrosion	visuai irispectiori				
If there is any liquid is leaked or deformation in	Visual inspection		0		
capacity	visuai irispectiori				

#### Cooling fan of cooling system

		Ма	laintenance	
Check Items	Methods and Criterion		Period	
		Daily	Half Year	One Year
	Visual, aural inspection and			
	turn the fan with hand (turn			
If there is any abnormal sound or vibration	off the power before		$\circ$	
	operation) to see if it rotates			
	smoothly			
If there is any loose screw	Tighten the screw		0	
If there is any color change due to overheat	Change fan		0	

#### Ventilation channel of cooling system

Check Items	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
If there is any obstruction in the heat sink, air intake or air outlet	Visual inspection		0	



Please use the neutral cloth for clean and use dust cleaner to remove dust when necessary.

## 6-2 Greasy Dirt Problem

Serious greasy dirt problems generally occur in processing industries such as machine tools, punching machines and so on. Please be aware of the possible damages that greasy oil may cause to your drive:

- 1. Electronic components that silt up with greasy oil may cause the drive to burn out or even explode.
- 2. Most greasy dirt contains corrosive substances that may damage the drive.

#### Solution:

Install the Hybrid servo drive in a standard cabinet to keep it away from dirt. Clean and remove greasy dirt regularly to prevent damage of the drive.





## 6-3 Fiber Dust Problem

Serious fiber dust problems generally occur in the textile industry. Please be aware of the possible damages that fiber may cause to your drives:

- Fiber that accumulates or adheres to the fans will lead to poor ventilation and cause overheating problems.
- 2. Plant environments in the textile industry have higher degrees of humidity that may cause the drive to burn out, become damaged or explode due to wet fiber dust adhering to the devices.

#### Solution:

Install the Hybrid servo drive in a standard cabinet to keep it away from fiber dust. Clean and remove fiber dust regularly to prevent damage to the drive.








## 6-4 Erosion Problem

Erosion problems may occur if any fluids flow into the drives. Please be aware of the damages that erosion may cause to your drive.


1. Erosion of internal components may cause the drive to malfunction and possibility to explode.

#### Solution:

Install the Hybrid servo drive in a standard cabinet to keep it away from fluids. Clean the drive regularly to prevent erosion.







## 6-5 Industrial Dust Problem

Serious industrial dust pollution frequently occurs in stone processing plants, flour mills, cement plants, and so on. Please be aware of the possible damage that industrial dust may cause to your drives:

- 1. Dust accumulating on electronic components may cause overheating problem and shorten the service life of the drive.
- 2. Conductive dust may damage the circuit board and may even cause the drive to explode.

#### Solution:

Install the Hybrid servo drive in a standard cabinet and cover the drive with a dust cover. Clean the cabinet and ventilation hole regularly for good ventilation.





## 6-6 Wiring and Installation Problem

When wiring the drive, the most common problem is wrong wire installation or poor wiring. Please be aware of the possible damages that poor wiring may cause to your drives:

- 1. Screws are not fully fastened. Occurrence of sparks as impedance increases.
- 2. If a customer has opened the drive and modified the internal circuit board, the internal components may have been damaged.

#### Solution:

Ensure all screws are fastened when installing the Hybrid servo drive. If the Hybrid servo drive functions abnormally, send it back to the repair station. DO NOT try to reassemble the internal components or wire.








## 6-7 Multi-function Input/Output Terminals Problem


Multi-function input/output terminal errors are generally caused by over usage of terminals and not following specifications. Please be aware of the possible damages that errors on multi-function input/output terminals may cause to your drives:


1. Input/output circuit may burns out when the terminal usage exceeds its limit.

#### Solution:

Refer to the user manual for multi-function input output terminals usage and follow the specified voltage and current. DO NOT exceed the specification limits.







# 7. Recommended Operations for Customers and Troubleshooting

7-1 Regular Maintenance and Check

7-2 Oil Contamination

7-3 Lint Issue

7-4 Corrosion Issue

7-5 Dust Issue

7-6 Installation and Wiring/Connection Issue

7-7 Multi-function Input/Output Terminal Application Issue

TheHybrid servo drive itself has warning messages and protection functions such as over-voltage, low-voltage, over-current, etc. Once a fault occurs, the protection function is activated, theHybrid servo drive stops output, and the motor comes to stop freely. Please look up the cause for the fault and perform the countermeasure according to the error message of theHybrid servo drive. The error records are stored in the internal memory of theHybrid servo drive (last six error messages can be recorded) and can be read out through the digital keypad or through the communication port.

TheHybrid servo drive consists of a large number of parts including ICs, resistors, capacitors, transistors, other electronic components, cooling fans, and relays, etc. These parts are not permanent and will eventually need replacing. Even in a normal environment, the components are prone to failure after the lifespan is reached. Therefore, preventive and regular inspection should be carried out so as to find out the part that does not meet the specifications or has poor quality so as to exclude the causes that may cause the failure of theHybrid servo drives. In addition, the inspection also helps the user to replace various parts that have reached their lifespan in order to ensure normal and safe operation.

It is necessary to visually inspect the operation of the Hybrid servo drives routinely to make sure that no abnormal condition occurs. Meanwhile, check if the following conditions occur:



- After a fault occurs, the RESET button will be effective only 5 seconds after the fault condition is released.
- ForHybrid servo drives of power rating  $\leq$  22kW, it is necessary to wait for 5 minutes (10 minutes for  $\geq$  30kW) after the power is shut down to confirm that the indicator light is off and the measured DC voltage across the terminals  $\oplus$  and  $\ominus$  is below DC 25V before opening the cover for inspection.
- ☑ Non-authorized personnel are not allowed to perform the maintenance work and component replacement operation, (Before operation, it is necessary to remove the metal objects such as watches and rings. Use insulated tools during the operation.)
- ☑ It is absolutely forbidden to modify the Hybrid servo drive.
- ☑ Make sure that the operational performance and surrounding environment meet the standards and there is no abnormal noise, vibration and odor.

## 7-1 Regular Maintenance and Check

For regular inspection, stop the machine operation, shut off the power, and remove the cover. Even the power supply of the Hybrid servo drive is disconnected, the filtering capacitor may still have charging voltage which may take some time to be discharged completely. To avoid danger, it is necessary to wait for the charging indicator to go off and use a voltmeter to test the voltage to confirm that the voltage is below a safe value ( $\leq 25 \text{Vdc}$ ) before the inspection operation can be started.

#### **Surrounding Environment**

		ection Period		
Inspection Item	Inspection Method	Daily	Half	One
			year	year
Check the ambient temperature, humidity,	Visual inspection and			
vibration, and if there is dust, gas, oil mist, water	measurement by	0		
droplets, etc.	instrument			
Is there any external object such as a tool or other	Visual inspection			
hazardous object around the device?		0		

#### Voltage

		ction P	eriod	
Inspection Item	Inspection Method	Daily	Half	One
			year	year
Are the voltages for the Main Circuit and the	Measurement by	0		
Control Circuit correct?	instrument			

#### **Keypad Display Panel**

		ction P	eriod	
Inspection Item	Inspection Method	Daily	Half	One
			year	year
Are the displayed messages readable?	Visual inspection	0		
Is there any omitted character?		0		

#### **Mechanical Parts**

		Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One	
			year	year	
Is there any abnormal sound or vibration?	Visual and auditory		0		
	inspection				
Are the bolts (fasteners) loose?	Fastening		0		
Is the part deformed or damaged?	Visual inspection		0		
Is the part discolored due to over heating?	Visual inspection		0		
Does the part have any dust or stain?	Visual inspection		0	_	

### **Main Circuit**

			Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One		
			year	year		
Are bolts loose or falling off?	Fastening	0				
Are the machine and insulators deformed,						
cracked, damaged, or discolored due to	Visual inspection		0			
over-heating and aging?						
Does the part have any dust or stain?	Visual inspection		0			

## Main Circuit - Terminals and Wiring

		ection Period		
Inspection Item	Inspection Method	Daily	Half	One
			year	year
Are the terminals and copper plates discolored or	Visual inspection		0	
deformed due to over heating?				
Is the shield layer of the wire damaged or	Visual inspection		0	
discolored?				

#### **Main Circuit – Terminal Block**

Inspection Item		Inspection Per				
	Inspection Method	Daily	Half	One		
			year	year		
Is it damaged?	Visual inspection	0				

## **Main Circuit - Filtering Capacitor**

		Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One	
			year	year	
Is there any leakage, discoloring, cracking, or	Visual inspection	0			
swollen housing?					
Does the safety valve not come out? Is the valve	Visual inspection	0			
body notably swollen?					
Measure the static capacitance as required.		0			

### **Main Circuit - Resistor**

			Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One		
			year	year		
Does the insulator have strange odor or crack due	Visual and auditory	0				
to over heating?	inspection					
Is the wire broken?	Visual inspection	0				
Is the connection joint damaged?	Measurement by	0				

	multi-meter				
--	-------------	--	--	--	--

#### **Main Circuit – Transformer and Reactor**

		Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One	
			year	year	
Is there any abnormal vibration or strange odor?	Visual and auditory				
	inspection	0			

## Main Circuit – Electromagnetic Contactor and Relay

		ection P	eriod	
Inspection Item	Inspection Method	Daily	Half	One
			year	year
Is there any vibration sound during operation?	Auditory inspection	0		
Does the contactor have good contact property?	Visual inspection	0		

#### **Control Circuit – Control PCB and Connectors**

		Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One	
			year	year	
Are the screws and connectors loose?	Fastening		0		
Is the part with a strange odor or discolored?	By smelling, visual		0		
	inspection				
Is there any cracked damaged, deformed, or	Visual inspection		0		
corroded part?					
Does the capacitor have any trace of leakage or	Visual inspection		0		
deformation?					

## **Cooling System – Cooling Fan**

		Inspection Period			
Inspection Item	Inspection Method	Daily	Half	One	
			year	year	
	Auditory and visual				
	inspection by manual				
Is there any abnormal sound or vibration?	rotating the fan. (It is		0		
	necessary to disconnect				
	the power)				
Are the bolts loose?	Fastening		0		
Id the part discolored due to over heating?	Visual inspection		0		

## **Cooling System – Ventilation Tunnel**

1 (* 1)	1 C NA (1 1	
Inspection Item	Inspection Method	Inspection Period

#### 7. Recommended Operations for Customers and Troubleshooting

		Daily	Half	One
			year	year
Are the inlet and outlet of the heat dissipation	Auditory inspection		0	
plate blocked or attached with external objects?				




The contaminated area should be wiped clean with a chemically neutral cloth. Use electrical cleaner to remove dust, etc.

## 7-2 Oil Contamination

Oil contamination is more serious for applications such as machine tools, presses, and other manufacturing industries. It is necessary to note the following:

- 1: When the oil accumulation around the electronic components, it may cause a short circuit between the components, resulting in blowing up the machine.
- 2: Most oils are slightly corrosive which may damage product easily.

Recommended measure: It is recommended that customers install the inverter in a dedicated cabinet and keep it as far as possible away from the oil spill. Meanwhile, regular cleaning procedure should also be performed to avoid oil spills damaging the inverter.





## 7-3 Lint Issue


Lint contamination is a serious issue for applications in the textile industries. It is necessary to note the following:

- 1: The lint often accumulates on the fans and other devices through the airflow. It may easily block the air duct of the inverter, resulting in over heating.
- 2: The textile industry usually has high humidity, so lint may enhance the condensation of moisture so that the components on the circuit board, leading to short-circuit and resulting in damage or blowing up the machine.

Recommended measures: may install the inverter in a dedicated cabinet. Meanwhile, a regular cleaning procedure should be performed to avoid lint accumulation in the inverter.










## 7-4 Corrosion Issue

Most of the applications with corrosive substances may have the issue of unknown liquid vertically flowing into the inverter; it should be noted: if the internal electronic components of the inverter are corroded, it may lead to malfunction or even blowing up.

Recommended measure: It is recommended that customers install the inverter in a dedicated cabinet and avoid liquid flowing into the inverter. Meanwhile, regular cleaning procedure should also be performed to prevent the inverter from corrosion damage.








## 7-5 Dust Issue

Dust contamination often occurs in the dusty environments such as the stone processing plants, flour mills, cement plants, etc. It is necessary to note the following:

- 1: When dust accumulates on the electronic components, it may cause over heating, thereby affecting the lifespan of the product.
- 2: In case of conductive dust, it is very likely to cause damage to the circuit or lead to possible blowing up.

Recommended measure: It is recommended that customers install the inverter in a dedicated cabinet and install a dust-proof cover. Meanwhile, regular cleaning procedure should also be performed to allow the inverter to dissipate the heat normally.





## 7-6 Installation and Wiring/Connection Issue

Notices for wiring: Most of such kind of faults usually occur when the customers perform improper wiring.

Impact on the product:

- (1) The screws for the wiring are not securely fastened so that the contact resistance is too high, resulting in arcing damage to the inverter.
- (2) If the customer arbitrarily modifies the internal circuit of the inverter, it may cause damage to the related parts.

Recommended measure: While installing the inverter, it is necessary to have all the screws fastened securely. If the machine has malfunction, please do not attempt to repair. Please return the product to the dedicated service center for repair!








## 7-7 Multi-function Input/Output Terminal Application Issue

Such kind of faults usually occur when the external I/O are used in a way exceeding their specifications. Notices for using the external I/O of the product: The components of the related I/O circuits may be burned by the extra-high energy, resulting in loss of function.

Recommended measure: While using such kind of I/O contacts, it is necessary to refer to the rated voltage and current indicated in the operation manual. Do not exceed the upper limit of the specifications.







# Appendix A Optional Accessories

- A-1 Braking Resistor Selection Chart
- A-2 Non-fuse Circuit Breaker
- A-3 Fuse Specification
- A-4 Reactor
- A-5 Digital Keypad KPV-CE01
- A-6 Speed Feedback PG Card Selection
- A-7 Communication Card
- A-8 EMI Filter



- ☑ This Hybrid servo drive has gone through rigorous quality control tests at the factory before shipment. If the package is damaged during shipping, please contact your dealer.
- ☑ The accessories produced by Delta are only for using with Delta Hybrid servo drive. Do NOT use with other drive to prevent damage.

# **A-1 Braking Resistor Selection Chart**

#### 230V

	cable otor	* 125% Braking Torque 10%ED					Maximum Braking Torque Limit		
HP	kW	Braking Unit VFDB* <sup>3</sup>	Braking Resistor the Correspondin *2		Effective Braking Resistance of Each Drive	I BIAKINO	Minimum Resistance Limit (Ω)	Highest Total Braking Current Limit (A)	Maximum Peak Power (kW)
7.5	5.5	-	BR1K0W020*1		1000W20Ω	19	15.6	24.4	9.3
10	7.5	-	BR1K5W013*1		1500W13Ω	29	11.5	33.0	12.5
15	11	-	BR1K5W(	)13*1	1500W13Ω	29	9.5	40.0	15.2
20	15	-	BR1K0W4P3*2	2 in series	2000W8.6Ω	44	8.3	46.0	17.5
25	18	-	BR1K2W3P9*2	2 in series	2400W7.8Ω	49	5.8	66.0	25.1
30	22	-	BR1K5W3P3*2	2 in series	3000W6.6Ω	58	5.8	66.0	25.1
40	30	2015*2	BR1K0W5P1*2	2 in series	4000W5.1Ω	75	4.8	80.0	30.4
50	37	2022*2	BR1K2W3P9*2	2 in series	4800W3.9Ω	97	3.2	120.0	45.6

#### 460V

Appli Mo	cable tor	*1 125% Braking Torqu		aking Torque	10%ED		Maximum Braking Tor		rque Limit	
ЦΠ	1444	Braking Unit	Braking Resistor Models for		Effective Braking E	Total Braking	Minimum	Highest Total	Maximum Peak	
HP	kW	VFDB* <sup>3</sup>	the Correspond Unit*	ully brake	Resistance of Each Drive	Current (A)	Resistance Limit (Ω)	Braking Current Limit (A)	Power (kW)	
7.5	5.5	-	BR1K0W	075*1	1000W75Ω	10.2	48.4	15.7	11.9	
10	7.5	-	BR1K5W	043*1	1500W43Ω	17.6	39.4	19.3	14.7	
15	11	-	BR1K5W043*1		1500W43Ω	17.6	30.8	24.7	18.8	
20	15	-	BR1K0W016*2	2 in series	2000W32Ω	24	25.0	30.4	23.1	
25	18	-	BR1K5W013*2	2 in series	3000W26Ω	29	20.8	36.5	27.7	
30	22	-	BR1K5W013*2	2 in series	3000W26Ω	29	19.0	40.0	30.4	
40	30	4030*1	BR1K0W5P1*4	4 in series	4000W20.4Ω	37	19.0	40.0	30.4	
50	37	4045*1	BR1K2W015*4	2 in parallel	4800W15Ω	50	12.7	60.0	45.6	
	01	10401	BI(11/2//010 4	2 in series	400011 1022	00	12.7	00.0	40.0	
60	45	4045*1	BR1K5W013*4	2 in parallel	6000W13Ω	59	12.7	60.0	45.6	
	.0		Brancovoro	2 in series	0000111012		12.7	00.0	10.0	
75	55	4030*2	BR1K0W5P1*4	4 in series	7200W10Ω	76	9.5	80.0	60.8	
100	75	4045*2	BR1K2W015*4	2 in parallel	9600W7.5Ω	100	6.3	120.0	91.2	
100	, 5		DK IN2VVU15"4	2 in series	3300777.322	100	0.3	120.0	01.2	

<sup>\*1</sup> Calculation for 125% brake toque: (kw)\*125%\*0.8; where 0.8 is motor efficiency.

Because there is a resistor limit of power consumption, the longest operation time for 10%ED is 10sec (on: 10sec/ off: 90sec).

<sup>\*&</sup>lt;sup>2</sup> For heat dissipation, a resistor of 400W or lower should be fixed to the frame and maintain the surface temperature below  $50^{\circ}$ C; a resistor of 1000W and above should maintain the surface temperature below  $350^{\circ}$ C.


<sup>\*3</sup> Please refer to VFDB series Braking Module Instruction for more detail on braking resistor.




1. Definition for Brake Usage ED%:

Explanation: The definition of the brake usage ED (%) is for assurance of enough time for the brake unit and brake resistor to dissipate away heat generated by braking. When the brake resistor heats up, the resistance would increase with temperature, and brake torque would decrease accordingly. Recommended cycle time is one minute.

Definition of Brake Usage ED%



For safety concern, install an overload relay (O.L) between the brake unit and the brake resistor in conjunction with the magnetic contactor (MC) prior to the drive for abnormal protection. The purpose of installing the thermal overload relay is to protect the brake resistor from damage due to frequent brake, or due to brake unit keeping operating resulted from unusual high input voltage. Under such circumstance, just turn off the power to prevent damaging the brake resistor.



Note1: When using the AC drive with DC reactor, please refer to wiring diagram in the AC drive user manual for the wiring of terminal +(P) of Braking unit.

Note2: Do NOT wire terminal -(N) to the neutral point of power system.


- 2. If damage to the drive or other equipment is due to the fact that the brake resistors and brake modules in use are not provided by Delta, the warranty will be void.
- 3. Take into consideration the safety of the environment when installing the brake resistors. If the minimum resistance value is to be utilized, consult local dealers for the calculation of Watt figures.
- 4. When using more than 2 brake units, equivalent resistor value of parallel brake unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each Hybrid Servo Drive" (the right-most column in the table). Please read the wiring information in the user manual of brake unit thoroughly prior to operation.
- 5. This chart is for normal usage; if the Hybrid servo drive is applied for frequent braking, it is suggested to enlarge 2~3 times of the Watts.


## **Specifications of VFDB Brake Unit**

Voltage Rating	9	230V Series		460V Series	
Model No. VF	DB-000	2015	2022	4030	4045
Maximum applicable motor capacity (KW)		15	22	30	45
Output	Peak Discharge Current	40	60	40	60
Rating	(Ipeak)10ED%				
	Continuous Discharge Current (A)	15	20	15	18
	Braking Start Voltage (DC)	330/345/360/38	0/400/415±3V	660/690/720/7	60/800/415±3V
Power Supply	DC Voltage	200~400VDC 400~800VI		00VDC	
	Over Heating of Heat Sink	Temperature Switch +95°C			
Protection	Fault output	Relay Contact 5A120Vac/28Vdc(RA.RB.RC)			
	Charge Indication	It goes off when the main loop (P-N) voltage is below 50VDC			
	Installation Location	Indoor	(no corrosive g	ases or metal d	lusts)
	Ambient temperature	-10°C∼+50°C			
Environment	Storage Temperature		-20°C∼	+60°C	
	Humidity	N	on-condensing	below 90%RH	
	Vibration	9.8m/S <sup>2</sup> (1G) for < 20Hz, 2m/S <sup>2</sup> (0.2G) for 20 – 50Hz			20 – 50Hz
IV	lechanical Construction	Wall Mount IP50			

### **Dimensions of Brake Unit**

Brake Unit: VFDB2015, VFDB2022, VFDB4030, and VFDB4045





# **A-2 Non-fuse Circuit Breaker**

Comply with UL standard: Per UL 508, paragraph 45.8.4, part a,

The rated current of the breaker shall be 2~4 times of the maximum rated input current of Hybrid servo drive.

dive.					
Three-phase					
Model	Recommended Current (A)				
VFD055VL23A-J	50				
VFD055VL43A-J	30				
VFD075VL23A-J	60				
VFD075VL43A-J	40				
VFD110VL23A-J	100				
VFD110VL43A-J	50				
VFD150VL23A-J	125				
VFD150VL43A-J	60				
VFD185VL23A-J	150				
VFD185VL43A-J	75				

Three-phase					
Model	Recommended Current (A)				
VFD220VL23A-J	175				
VFD220VL43A-J	100				
VFD300VL23A-J	225				
VFD300VL43A-J	125				
VFD370VL23A-J	250				
VFD370VL43A-J	150				
VFD450VL43A-J	175				
VFD550VL43A-J	250				
VFD750VL43A-J	300				

# **A-3 Fuse Specifications**

Smaller fuses than those shown in the table are permitted

230V Series	Input Current I (A)	Line	Fuse	
200 V Genes	input Current i (A)	I (A)	Bussmann P/N	
VFD055VL23A-J	25	50	JJN-50	
VFD075VL23A-J	31	60	JJN-60	
VFD110VL23A-J	47	100	JJN-100	
VFD150VL23A-J	60	125	JJN-125	
VFD185VL23A-J	80	150	JJN-150	
VFD220VL23A-J	90	175	JJN-175	
VFD300VL23A-J	106	225	JJN-225	
VFD370VL23A-J	126	250	JJN-250	

460V Series	Input Current I (A)	Line Fuse			
400V Series	Input Current I (A)	I (A)	Bussmann P/N		
VFD055VL43A-J	14	30	JJN-30		
VFD075VL43A-J	18	40	JJN-40		
VFD110VL43A-J	24	50	JJN-50		
VFD150VL43A-J	31	60	JJN-60		
VFD185VL43A-J	39	75	JJN-70		
VFD220VL43A-J	47	100	JJN-100		
VFD300VL43A-J	56	125	JJN-125		
VFD370VL43A-J	67	150	JJN-150		
VFD450VL43A-J	87	175	JJN-175		
VFD550VL43A-J	101	250	JJN-250		
VFD750VL43A-J	122	300	JJN-300		

## **A-4 Reactor**

## A-4-1 AC Input Reactor Recommended Value

460V, 50/60Hz, Three-phase

kW	HP	Rated Current	Maximum	Inductar	nce (mh)
KVV   TP		of Reactor	Continuous Current	3% Impedance	5% Impedance
5.5	7.5	12	18	2.5	4.2
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	35	52.5	0.8	1.2
22	30	45	67.5	0.7	1.2
30	40	55	82.5	0.5	0.85
37	50	80	120	0.4	0.7
45	60	80	120	0.4	0.7
55	75	100	150	0.3	0.45
75	100	130	195	0.2	0.3

## A-4-2 AC Output Reactor Recommended Value

230V, 50/60Hz, Three-phase

		•			
kW	HP	Rated Current	Maximum	Inductar	nce (mh)
KVV	I IF	of Reactor	Continuous Current	3% Impedance	5% Impedance
5.5	7.5	25	37.5	0.5	1.2
7.5	10	35	52.5	0.4	8.0
11	15	55	82.5	0.25	0.5
15	20	80	120	0.2	0.4
18.5	25	80	120	0.2	0.4
22	30	100	150	0.15	0.3
30	40	130	195	0.1	0.2
37	50	160	240	0.075	0.15

460V, 50/60Hz, Three-phase

kW	HP	Rated Current	Maximum	Inductar	nce (mh)
KVV	ПР	of Reactor	Continuous Current	3% Impedance	5% Impedance
5.5	7.5	18	27	1.5	2.5
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	45	67.5	0.7	1.2
22	30	45	67.5	0.7	1.2
30	40	80	120	0.4	0.7
37	50	80	120	0.4	0.7
45	60	100	150	0.3	0.45
55	75	130	195	0.2	0.3
75	100	160	240	0.15	0.23

## **Application Example of AC Reactor**


Connected in input circuit

#### Application 1

When more than one Hybrid servo drive is connected to the same mains power and one of them is ON during operation.

Problem: When applying power to one of the Hybrid servo drive, the charge current of the capacitors may cause voltage dip. The Hybrid servo drive may be damaged when over current occurs during operation.

#### Correct wiring:




#### Application 2

Silicon rectifier and Hybrid servo drive are connected to the same power.

Problem: Switching spikes will be generated when the silicon rectifier switches ON/OFF. These spikes may damage the mains circuit.


#### Correct wiring:




### Application 3

When the power supply capacity exceeds 10 times of the inverter capacity.


Problem: When the mains power capacity is too large, line impedance will be small and the charge current will be too high. This may damage Hybrid servo drive due to higher rectifier temperature.





## A-4-3 Zero-phase Reactor

RF220X00A UNIT: mm (inch)



Cable Type		comm e Size	Qty.	Wiring	
(Note)	AWG	mm <sup>2</sup>	Nominal (mm²)	Qty.	Method
Single-	≤10	≤5.3	≤5.5	1	Figure A
core	≤2	≤33.6	≤38	4	Figure B
Three-	≤12	≤3.3	≤3.5	1	Figure A
core	≤1	≤42.4	≤50	4	Figure B



600V insulated power line.

- The table above gives approximate wire size for the zero phase reactors but the selection is ultimately governed by the type and diameter of cable fitted i.e. the cable must fit through the center hole of zero phase reactors.
- 2. Only the phase conductors should pass through, not the earth core or screen.
- When long motor output cables are used an output zero phase reactor may be required to reduce radiated emissions from the cable.

Figure A

Please wind each wire 4 times around the core. The reactor must be put at inverter output as close as possible.





Figure B

Please put all wires through 4 cores in series without winding.



## A-4-4 DC Reactor

### 230V DC Choke

Input Voltage	kW	HP	DC Amps	Inductance (mh)
	5.5	7.5	32	0.85
	7.5	10	40	0.75
220)/	11	15	62	Built-in
230Vac	15	20	92	Built-in
50/60Hz 3-Phase	18.5	25	110	Built-in
5-Filase	22	30	125	Built-in
	30	40	-	Built-in
	37	50	-	Built-in


#### 460V DC Choke

Input Voltage	kW	HP	DC Amps	Inductance (mh)
	5.5	7.5	18	3.75
	7.5	10	25	4.00
	11	15	32	Built-in
	15	20	50	Built-in
460Vac	18.5	25	62	Built-in
50/60Hz	22	30	80	Built-in
3-Phase	30	40	92	Built-in
	37	50	110	Built-in
	45	60	125	Built-in
	55	75	200	Built-in
	75	100	240	Built-in

# A-5 Digital Keypad KPV-CE01

The VFD-VJ series products use the digital keypad VFD-KPV-CE01 as the display unit. For the actual keypad appearance, please refer to the actual product. This picture shows the schematic diagram for illustrative purposes only.

## **Keypad Panel Appearance**




## Description of Displayed Function Items

Displayed Item	Description
F 8000	Show the current frequency set for the Hybrid servo drive.
<b>*</b> 5000	Show the frequency Hybrid servo drive actually delivers to the motor.
u 18088	Show the user-defined physical value (U = F x 00-05)
8 5.8	Show the load current
c 28	Show the value of the counter
81-88	Show the selected parameter
18	Show the parameter value


88	Show the external error
-End-	If the message "End" is displayed (as shown in the left figure) for approximately 1 second, it means that the data have been accepted and automatically stored in the internal memory
-8	If the configured data are not accepted or the values exceed the limits, this message will be displayed

## **Keypad Panel Operation Process**




#### To copy parameters 1

Copy parameters from the AC Motor Drive to the KPV-CE01




#### To copy parameters 2


Copy parameters from the KPV-CE01 to the AC Motor Drive




## **Mechanical Dimensions of Digital Keypad KPV-CE01**

Unit: mm [inch]








## **Characters of Digital Keypad Displayed on the LCD**

Number	0	1	2	3	4	5	6	7	8	9
LCD	0	;	2	3	4	5	8	7-	8	9
Eng. Letter	Α	b	Сс	d	Е	F:.	G	Hh	I	Jj
LCD	8	ь	[ ]	ď	Ε	F	5	X X	;	<i>J</i> 5
Eng. Letter	K	L	n	Oo	Р	q	r	S	Tt	U
LCD	۲	L	n	0 0	P	9	•	5	75	U
Eng. Letter	V	Υ	Z							
LCD	L	3	-							

# A-6 Speed Feedback PG Card Selection


### EMVJ-PG01R/PG02R





Layout of J1 Drive Connector

### **Function of J1 Terminal**



Pin No	Terminal Mark	Function, Description	Specifications
4	SIN- (S4)		
5	SIN+ (S2)	Decelver Cianal Output	2 5 10 175\/rma 10kH=
7	COS+ (S1)	Resolver Signal Output	3.5±0.175Vrms, 10kHz
9	COS- (S3)		
14,16	REF+ (R1)	Decelver Dower Input	7\/rma_10\/L
13,15	REF- (R2)	Resolver Power Input	7Vrms, 10kHz
	Shield	Shield	


## **Wiring Length**

Encoder Wiring - Diameter mm² (AWG)					
Core Size	Number of Cores	Wire Standard	Standard Wire Length		
0.13 (AWG26)	10 (4 pairs)	UL2464	3 m (9.84 feet)		



- 1) For wiring the encoder, please use the shielded twisted-pair cable so as to reduce the interference due to noise.
- 2) The shield net must be firmly connected with the SHIELD terminal
- 3) During wiring, please follow the corresponding provisions for cable wiring so as to avoid hazards and accidents.


## **Connector Specifications**




Title	Part No.	Manufacturer
PLUG	3M 10120-3000PE	3M
SHELL	3M 10320-52A0-008	3M

## EMVJ-PG01U







Layout of J1 Drive Connector

## **Functions of Terminals**

Pin No	Terminal Mark	Function, Description	Specifications
4	Ā		
5	Α		
7	В	Differential incremental signal input of	Line Driver (Line Driver RS422)
9	$\overline{\overline{B}}$	the encoder	Maximum Input Frequency 300kHz
10	Z		
2	$\bar{\overline{Z}}$		
14, 16	VP	Encoder power output  Note: FSW3 can be used to configure the output as +5V or +12V.	Voltage: +5V±0.5V or +12V±1V  Current: 200mA max
13, 15	0V	Power common dedicated for the encoder	Reference level for the encoder power
19	U		
8	$\overline{\mathrm{U}}$		
6	V	Differential absolute signal input of the	Line Driver (Line Driver RS422)
1	$\overline{V}$	encoder (UVW 3-bit encoding)	Maximum Input Frequency 50kHz
11	W		
3	$\overline{\mathbf{W}}$		


## Wiring Length

Encoder Wiring - Diameter mm² (AWG)				
Core Size Number of Cores		Wire Standard	d Standard Wire Length	
0.13 (AWG26)	10 (4 pairs)	UL2464	3 m (9.84 feet)	



- 1) For wiring the encoder, please use the shielded twisted-pair cable so as to reduce the interference due to noise.
- 2) The shield net must be firmly connected with the SHIELD terminal .
- 3) During wiring, please follow the corresponding provisions for cable wiring so as to avoid hazards and accidents.

## **Connector Specifications**



Title	Part No.	Manufacturer
PLUG	3M 10120-3000PE	3M
SHELL	3M 10320-52A0-008	3M

# A-7 Communication Card

#### EMVJ-MF01



Terminal	Description		
	Ground terminal		
SG-	RS485 terminals		
SG-	R3460 (eminals		
GND	Common ground for signals		

## NOTE

- 1. For wiring, please use the shielded twisted-pair cable so as to reduce the interference due to noise.
- 2. The shield net must be firmly connected with the SHIELD terminal  $\stackrel{ ext{ }}{\oplus}$  .

## A-8 EMI Filter

Drive	Applicable Filter Model No.	Reference Website
VFD055VL23A-J	KMF336A	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD075VL23A-J		KMF336A Three Phase Industrial Mains Filters - High Performance 36 Amps
VFD150VL43A-J		
VFD055VL23A-J		http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD150VL43A-J	KMF350A	KMF350 Three Phase Industrial Mains Filters - General Purpose 50 Amps
VFD220VL43A-J		
VFD150VL43A-J		http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD300VL43A-J	KMF370A	KMF336A Three Phase Industrial Mains Filters - High Performance 70 Amps
VFD370VL43A-J		
VFD185VL23A-J		http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD220VL23A-J	KMF3100A	KMF3100A Three Phase Industrial Mains Filters - High Performance 100 Amps
VFD450VL43A-J		
VFD300VL23A-J		http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD370VL23A-J	KMF3150A	KMF3150A Three Phase Industrial Mains Filters - High Performance 150 Amps
VFD550VL43A-J	KIVIF3 150A	
VFD750VL43A-J		
VFD055VL43A-J	KMF318A	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD055VL43A-J		KMF318 Three Phase Industrial Mains Filters - General Purpose 18 Amps
VFD075VL43A-J	KMF325A	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD110VL43A-J	KIVIF 325A	KMF325A Three Phase Industrial Mains Filters - High Performance 25 Amps

#### **EMI Filter Installation**

All electrical equipment, including Hybrid drives, will generate high-frequency/low-frequency noise and will interfere with peripheral equipment by radiation or conduction when in operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when Hybrid drive and EMI filter are installed and wired according to user manual:

- EN61000-6-4
- EN61800-3: 1996
- EN55011 (1991) Class A Group 1 (1<sup>st</sup> Environment, restricted distribution)

#### **General precaution**

- 1. EMI filter and Hybrid drive should be installed on the same metal plate.
- 2. Please install Hybrid drive on footprint EMI filter or install EMI filter as close as possible to the Hybrid drive.
- 3. Please wire as short as possible.
- 4. Metal plate should be grounded.
- 5. The cover of EMI filter and Hybrid drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

#### Choose suitable motor cable and precautions

Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to observe the following precautions when selecting motor cable.

- 1. Use the cable with shielding (double shielding is the best).
- The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
- 3. Remove any paint on metal saddle for good ground contact with the plate and shielding.

Remove any paint on metal saddle for good ground contact with the plate and shielding.




Figure 2

#### The length of motor cable

When motor is driven by an Hybrid drive of PWM type, the motor terminals will experience surge voltages easily due to components conversion of Hybrid drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may reduce insulation quality. To prevent this situation, please follow the rules below:

- Use a motor with enhanced insulation.
- Connect an output reactor (optional) to the output terminals of the Hybrid drive
- The length of the cable between Hybrid drive and motor should be as short as possible (10 to 20 m or less)
- For models 7.5hp and above:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	328 ft (100m)	1312 ft (400m)

230VAC input voltage	1312 ft (400m)	1312 ft (400m)	1312 ft (400m)
	,	,	,

#### ■ For models 5hp and less:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	165 ft (50m)	165 ft (50m)
230VAC input voltage	328 ft (100m)	328 ft (100m)	328 ft (100m)



Never connect phase lead capacitors or surge absorbers to the output terminals of the Hybrid drive.

- If the length is too long, the stray capacitance between cables will increase and may cause leakage current. It will activate the protection of over current, increase leakage current or not insure the correction of current display. The worst case is that Hybrid drive may damage.
- If more than one motor is connected to the Hybrid drive, the total wiring length is the sum of the wiring length from Hybrid drive to each motor.
- For the 460V series Hybrid drive, when an overload relay is installed between the drive and the motor to protect motor over heating, the connecting cable must be shorter than 50m. However, an overload relay malfunction may still occur. To prevent the malfunction, install an output reactor (optional) to the drive or lower the carrier frequency setting (Pr.00-17).



When a thermal O/L relay protected by motor is used between Hybrid drive and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use AC reactor and/or lower the carrier frequency (Pr. 00-17 PWM carrier frequency).